

PROGRESSIVE ORIGINAL REFERENCES



PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
0501 305 887	T08940	003 264 2252	ZF 37	64	GEAR THRUST WASHER	16 S 112
0501 305 887	T08940	003 264 2252	ZF 40	64	GEAR THRUST WASHER	16 K 130
0501 305 887	T08940	003 264 2252	ZF 41	64	GEAR THRUST WASHER	16 S 130
0501 306 212			ZF 41	64	GEAR THRUST WASHER	16 S 130
0501 306 212			ZF 43	64	GEAR THRUST WASHER	16 K 160
0501 306 212			ZF 44	64	GEAR THRUST WASHER	16 S 160
0501 306 212			ZF 46	64	GEAR THRUST WASHER	16 K 190
0501 306 212			ZF 47	64	GEAR THRUST WASHER	16 S 190
0501 306 212			ZF 51	64	GEAR THRUST WASHER	16 S 220
0501 308 981			ZF 47	64	GEAR THRUST WASHER	16 S 190
0501 308 981			ZF 50	64	GEAR THRUST WASHER	16 S 150
0501 308 981			ZF 51	64	GEAR THRUST WASHER	16 S 220
0501 308 981			ZF 55	64	GEAR THRUST WASHER	16 S 151
0501 308 981			ZF 57	64	GEAR THRUST WASHER	16 S 221
0631 329 017			ZF 37	63	GEAR SHAFT ELASTIC PIN	16 S 112
0631 329 017			ZF 40	63	GEAR SHAFT ELASTIC PIN	16 K 130
0631 329 017			ZF 41	63	GEAR SHAFT ELASTIC PIN	16 S 130
0631 329 017			ZF 43	63	GEAR SHAFT ELASTIC PIN	16 K 160
0631 329 017			ZF 44	63	GEAR SHAFT ELASTIC PIN	16 S 160
0631 329 017			ZF 46	63	GEAR SHAFT ELASTIC PIN	16 K 190
0631 329 017			ZF 47	63	GEAR SHAFT ELASTIC PIN	16 S 190
0631 329 050			ZF 40	62	GEAR SHAFT ELASTIC PIN	16 K 130
0631 329 050			ZF 43	62	GEAR SHAFT ELASTIC PIN	16 K 160
0631 329 050			ZF 46	62	GEAR SHAFT ELASTIC PIN	16 K 190
0631 329 050			ZF 37	62	GEAR SHAFT ELASTIC PIN	16 S 112
0631 329 050			ZF 41	62	GEAR SHAFT ELASTIC PIN	16 S 130
0631 329 050			ZF 44	62	GEAR SHAFT ELASTIC PIN	16 S 160
0631 329 050			ZF 47	62	GEAR SHAFT ELASTIC PIN	16 S 190
0631 329 051			ZF 47	62	GEAR SHAFT ELASTIC PIN	16 S 190
0631 329 051			ZF 50	62	GEAR SHAFT ELASTIC PIN	16 S 150
0631 329 051			ZF 51	62	GEAR SHAFT ELASTIC PIN	16 S 220
0631 329 051			ZF 55	62	GEAR SHAFT ELASTIC PIN	16 S 151
0631 329 051			ZF 56	62	GEAR SHAFT ELASTIC PIN	16 S 181
0631 329 051			ZF 57	62	GEAR SHAFT ELASTIC PIN	16 S 221
0631 329 051			ZF 58	62	GEAR SHAFT ELASTIC PIN	16 S 251
0631 329 167			ZF 47	63	GEAR SHAFT ELASTIC PIN	16 S 190
0631 329 167			ZF 50	63	GEAR SHAFT ELASTIC PIN	16 S 150
0631 329 167			ZF 51	63	GEAR SHAFT ELASTIC PIN	16 S 220
0631 329 167			ZF 55	63	GEAR SHAFT ELASTIC PIN	16 S 151
0631 329 167			ZF 56	63	GEAR SHAFT ELASTIC PIN	16 S 181
0631 329 167			ZF 57	63	GEAR SHAFT ELASTIC PIN	16 S 221
0631 329 167			ZF 58	63	GEAR SHAFT ELASTIC PIN	16 S 251
0635 470 012			ZF 37	6	SYNCHRONIZER CYLINDER ROLLER	16 S 112
0635 470 012			ZF 40	5	SYNCHRONIZER CYLINDER ROLLER	16 K 130
0635 470 012			ZF 41	6	SYNCHRONIZER CYLINDER ROLLER	16 S 130
0635 470 012			ZF 43	5	SYNCHRONIZER CYLINDER ROLLER	16 K 160
0635 470 012			ZF 44	6	SYNCHRONIZER CYLINDER ROLLER	16 S 160
0635 470 012			ZF 46	6	SYNCHRONIZER CYLINDER ROLLER	16 K 190
0635 470 012			ZF 47	6	SYNCHRONIZER CYLINDER ROLLER	16 S 190
0635 470 012			ZF 50	6	SYNCHRONIZER CYLINDER ROLLER	16 S 150
0635 470 012			ZF 51	6	SYNCHRONIZER CYLINDER ROLLER	16 S 220
0730 062 323			ZF 37	10	MAIN DRIVE GEAR TUBE	16 S 112
0730 062 323			ZF 40	9	MAIN DRIVE GEAR TUBE	16 K 130
0730 062 323			ZF 41	10	MAIN DRIVE GEAR TUBE	16 S 130
0730 062 323			ZF 43	9	MAIN DRIVE GEAR TUBE	16 K 160
0730 062 323			ZF 44	10	MAIN DRIVE GEAR TUBE	16 S 160
0730 062 323			ZF 46	10	MAIN DRIVE GEAR TUBE	16 K 190
0730 062 323			ZF 47	10	MAIN DRIVE GEAR TUBE	16 S 190
0730 103 846	T08939	003 264 2052	ZF 37	65	GEAR SPACER RING	16 S 112
0730 103 846	T08939	003 264 2052	ZF 40	65	GEAR SPACER RING	16 K 130
0730 103 846	T08939	003 264 2052	ZF 41	65	GEAR SPACER RING	16 S 130
0730 103 846	T08939	003 264 2052	ZF 43	65	GEAR SPACER RING	16 K 160
0730 103 846	T08939	003 264 2052	ZF 44	65	GEAR SPACER RING	16 S 160
0730 103 846	T08939	003 264 2052	ZF 46	65	GEAR SPACER RING	16 K 190
0730 103 846	T08939	003 264 2052	ZF 47	65	GEAR SPACER RING	16 S 190
0730 103 846	T08939	003 264 2052	ZF 51	65	GEAR SPACER RING	16 S 220
0730 107 168			ZF 47	65	GEAR SPACER RING	16 S 190
0730 107 168			ZF 50	65	GEAR SPACER RING	16 S 150
0730 107 168			ZF 51	65	GEAR SPACER RING	16 S 220
0730 107 168			ZF 55	65	GEAR SPACER RING	16 S 151
0730 107 168			ZF 56	64	GEAR SPACER RING	16 S 181
0730 107 168			ZF 56	66	GEAR SPACER RING	16 S 181
0730 107 168			ZF 57	65	GEAR SPACER RING	16 S 221
0730 109 309			ZF 56	66	GEAR SPACER RING	16 S 181
0730 109 309			ZF 57	67	GEAR SPACER RING	16 S 221
0730 109 323			ZF 56	64	GEAR SPACER RING	16 S 181

I riferimenti originali sono riportati solo come indicazione di particolari originali corrispondenti.
 All manufactures' names, numbers, symbols and descriptions are used for reference purposes only, and it is not implied that any part listed is the product of these manufacturers.

PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
0730 109 323			ZF 57	65	GEAR SPACER RING	16 S 221
0730 109 323			ZF 58	64	GEAR SPACER RING	16 S 251
0730 150 064	T14283	343 263 0062	ZF 37	35	REVERSE IDLER GEAR THRUST WASHER	16 S 112
0730 150 064	T14283	343 263 0062	ZF 40	30	REVERSE IDLER GEAR THRUST WASHER	16 K 130
0730 150 064	T14283	343 263 0062	ZF 41	35	REVERSE IDLER GEAR THRUST WASHER	16 S 130
0730 150 064	T14283	343 263 0062	ZF 43	31	REVERSE IDLER GEAR THRUST WASHER	16 K 160
0730 150 064	T14283	343 263 0062	ZF 44	36	REVERSE IDLER GEAR THRUST WASHER	16 S 160
0730 150 064	T14283	343 263 0062	ZF 46	32	REVERSE IDLER GEAR THRUST WASHER	16 K 190
0730 150 064	T14283	343 263 0062	ZF 47	36	REVERSE IDLER GEAR THRUST WASHER	16 S 190
0730 150 064	T14283	343 263 0062	ZF 50	42	REVERSE IDLER GEAR THRUST WASHER	16 S 150
0730 150 064	T14283	343 263 0062	ZF 51	42	REVERSE IDLER GEAR THRUST WASHER	16 S 220
0730 162 801			ZF 58	66	GEAR SPACER BUSHING	16 S 251
0732 040 385	T08950	336 264 0693	ZF 37	7	SYNCHRONIZER PRESSURE SPRING, OUTER	16 S 112
0732 040 385	T08950	336 264 0693	ZF 37	74	SYNCHRONIZER PRESSURE SPRING, OUTER	16 S 112
0732 040 385	T08950	336 264 0693	ZF 40	6	SYNCHRONIZER PRESSURE SPRING, OUTER	16 K 130
0732 040 385	T08950	336 264 0693	ZF 40	74	SYNCHRONIZER PRESSURE SPRING, OUTER	16 K 130
0732 040 385	T08950	336 264 0693	ZF 41	7	SYNCHRONIZER PRESSURE SPRING, OUTER	16 S 130
0732 040 385	T08950	336 264 0693	ZF 41	74	SYNCHRONIZER PRESSURE SPRING, OUTER	16 S 130
0732 040 385	T08950	336 264 0693	ZF 43	6	SYNCHRONIZER PRESSURE SPRING, OUTER	16 K 160
0732 040 385	T08950	336 264 0693	ZF 43	74	SYNCHRONIZER PRESSURE SPRING, OUTER	16 K 160
0732 040 385	T08950	336 264 0693	ZF 44	7	SYNCHRONIZER PRESSURE SPRING, OUTER	16 S 160
0732 040 385	T08950	336 264 0693	ZF 44	74	SYNCHRONIZER PRESSURE SPRING, OUTER	16 S 160
0732 040 385	T08950	336 264 0693	ZF 46	7	SYNCHRONIZER PRESSURE SPRING, OUTER	16 K 190
0732 040 385	T08950	336 264 0693	ZF 46	74	SYNCHRONIZER PRESSURE SPRING, OUTER	16 K 190
0732 040 385	T08950	336 264 0693	ZF 47	7	SYNCHRONIZER PRESSURE SPRING, OUTER	16 S 190
0732 040 385	T08950	336 264 0693	ZF 47	74	SYNCHRONIZER PRESSURE SPRING, OUTER	16 S 190
0732 040 385	T08950	336 264 0693	ZF 50	74	SYNCHRONIZER PRESSURE SPRING, OUTER	16 S 150
0732 040 385	T08950	336 264 0693	ZF 51	74	SYNCHRONIZER PRESSURE SPRING, OUTER	16 S 220
0732 040 385	T08950	336 264 0693	ZF 55	74	SYNCHRONIZER PRESSURE SPRING, OUTER	16 S 151
0732 040 385	T08950	336 264 0693	ZF 56	75	SYNCHRONIZER PRESSURE SPRING, OUTER	16 S 181
0732 040 385	T08950	336 264 0693	ZF 57	75	SYNCHRONIZER PRESSURE SPRING, OUTER	16 S 221
0732 040 385	T08950	336 264 0693	ZF 58	76	SYNCHRONIZER PRESSURE SPRING, OUTER	16 S 251
0732 040 386	T08951	336 264 0793	ZF 37	8	SYNCHRONIZER PRESSURE SPRING, INNER	16 S 112
0732 040 386	T08951	336 264 0793	ZF 37	75	SYNCHRONIZER PRESSURE SPRING, INNER	16 S 112
0732 040 386	T08951	336 264 0793	ZF 40	7	SYNCHRONIZER PRESSURE SPRING, INNER	16 K 130
0732 040 386	T08951	336 264 0793	ZF 40	75	SYNCHRONIZER PRESSURE SPRING, INNER	16 K 130
0732 040 386	T08951	336 264 0793	ZF 41	8	SYNCHRONIZER PRESSURE SPRING, INNER	16 S 130
0732 040 386	T08951	336 264 0793	ZF 41	75	SYNCHRONIZER PRESSURE SPRING, INNER	16 S 130
0732 040 386	T08951	336 264 0793	ZF 43	7	SYNCHRONIZER PRESSURE SPRING, INNER	16 K 160
0732 040 386	T08951	336 264 0793	ZF 43	75	SYNCHRONIZER PRESSURE SPRING, INNER	16 K 160
0732 040 386	T08951	336 264 0793	ZF 44	8	SYNCHRONIZER PRESSURE SPRING, INNER	16 S 160
0732 040 386	T08951	336 264 0793	ZF 44	75	SYNCHRONIZER PRESSURE SPRING, INNER	16 S 160
0732 040 386	T08951	336 264 0793	ZF 46	8	SYNCHRONIZER PRESSURE SPRING, INNER	16 K 190
0732 040 386	T08951	336 264 0793	ZF 46	75	SYNCHRONIZER PRESSURE SPRING, INNER	16 K 190
0732 040 386	T08951	336 264 0793	ZF 47	8	SYNCHRONIZER PRESSURE SPRING, INNER	16 S 190
0732 040 386	T08951	336 264 0793	ZF 47	75	SYNCHRONIZER PRESSURE SPRING, INNER	16 S 190
0732 040 386	T08951	336 264 0793	ZF 50	75	SYNCHRONIZER PRESSURE SPRING, INNER	16 S 150
0732 040 386	T08951	336 264 0793	ZF 51	75	SYNCHRONIZER PRESSURE SPRING, INNER	16 S 220
0732 040 386	T08951	336 264 0793	ZF 55	75	SYNCHRONIZER PRESSURE SPRING, INNER	16 S 151
0732 040 386	T08951	336 264 0793	ZF 56	76	SYNCHRONIZER PRESSURE SPRING, INNER	16 S 181
0732 040 386	T08951	336 264 0793	ZF 57	76	SYNCHRONIZER PRESSURE SPRING, INNER	16 S 221
0732 040 386	T08951	336 264 0793	ZF 58	77	SYNCHRONIZER PRESSURE SPRING, INNER	16 S 251
0732 040 409	T13440	005 993 6101	ZF 50	7	SYNCHRONIZER PRESSURE SPRING	16 S 150
0732 040 409	T13440	005 993 6101	ZF 51	7	SYNCHRONIZER PRESSURE SPRING	16 S 220
0732 040 409	T13440	005 993 6101	ZF 55	5	SYNCHRONIZER PRESSURE SPRING	16 S 151
0732 040 409	T13440	005 993 6101	ZF 56	5	SYNCHRONIZER PRESSURE SPRING	16 S 181
0732 040 409	T13440	005 993 6101	ZF 57	5	SYNCHRONIZER PRESSURE SPRING	16 S 221
0732 040 409	T13440	005 993 6101	ZF 58	5	SYNCHRONIZER PRESSURE SPRING	16 S 251
0735 470 057	T08936	001 981 1187	ZF 37	66	GEAR NEEDLE ROLLER	16 S 112
0735 470 057	T08936	001 981 1187	ZF 40	66	GEAR NEEDLE ROLLER	16 K 130
0735 470 057	T08936	001 981 1187	ZF 41	66	GEAR NEEDLE ROLLER	16 S 130
0735 470 164			ZF 50	66	GEAR NEEDLE ROLLER	16 S 150
0735 470 164			ZF 55	66	GEAR NEEDLE ROLLER	16 S 151
0750 119 109			ZF 41	66	GEAR NEEDLE ROLLER	16 S 130
0750 119 109			ZF 43	66	GEAR NEEDLE ROLLER	16 K 160
0750 119 109			ZF 44	66	GEAR NEEDLE ROLLER	16 S 160
0750 119 109			ZF 46	66	GEAR NEEDLE ROLLER	16 K 190
0750 119 109			ZF 47	66	GEAR NEEDLE ROLLER	16 S 190
0750 119 116			ZF 47	66	GEAR NEEDLE ROLLER	16 S 190
0750 119 116			ZF 51	66	GEAR NEEDLE ROLLER	16 S 220
0750 119 116			ZF 55	66	GEAR NEEDLE ROLLER	16 S 151
0750 119 116			ZF 56	65	GEAR NEEDLE ROLLER	16 S 181
0750 119 116			ZF 57	66	GEAR NEEDLE ROLLER	16 S 221
0750 119 116			ZF 58	65	GEAR NEEDLE ROLLER	16 S 251
1240 304 278	T08949	336 264 0239	ZF 37	9	SYNCHRONIZER PRESSURE PLUNGER	16 S 112
1240 304 278	T08949	336 264 0239	ZF 37	76	SYNCHRONIZER PRESSURE PLUNGER	16 S 112

PROGRESSIVE ORIGINAL REFERENCES



PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
1240 304 278	T08949	336 264 0239	ZF 40	8	SYNCHRONIZER PRESSURE PLUNGER	16 K 130
1240 304 278	T08949	336 264 0239	ZF 40	76	SYNCHRONIZER PRESSURE PLUNGER	16 K 130
1240 304 278	T08949	336 264 0239	ZF 41	9	SYNCHRONIZER PRESSURE PLUNGER	16 S 130
1240 304 278	T08949	336 264 0239	ZF 41	76	SYNCHRONIZER PRESSURE PLUNGER	16 S 130
1240 304 278	T08949	336 264 0239	ZF 43	8	SYNCHRONIZER PRESSURE PLUNGER	16 K 160
1240 304 278	T08949	336 264 0239	ZF 43	76	SYNCHRONIZER PRESSURE PLUNGER	16 K 160
1240 304 278	T08949	336 264 0239	ZF 44	9	SYNCHRONIZER PRESSURE PLUNGER	16 S 160
1240 304 278	T08949	336 264 0239	ZF 44	76	SYNCHRONIZER PRESSURE PLUNGER	16 S 160
1240 304 278	T08949	336 264 0239	ZF 46	9	SYNCHRONIZER PRESSURE PLUNGER	16 K 190
1240 304 278	T08949	336 264 0239	ZF 46	76	SYNCHRONIZER PRESSURE PLUNGER	16 K 190
1240 304 278	T08949	336 264 0239	ZF 47	9	SYNCHRONIZER PRESSURE PLUNGER	16 S 190
1240 304 278	T08949	336 264 0239	ZF 47	76	SYNCHRONIZER PRESSURE PLUNGER	16 S 190
1240 304 278	T08949	336 264 0239	ZF 50	76	SYNCHRONIZER PRESSURE PLUNGER	16 S 150
1240 304 278	T08949	336 264 0239	ZF 51	76	SYNCHRONIZER PRESSURE PLUNGER	16 S 220
1240 304 278	T08949	336 264 0239	ZF 55	76	SYNCHRONIZER PRESSURE PLUNGER	16 S 151
1240 304 278	T08949	336 264 0239	ZF 56	77	SYNCHRONIZER PRESSURE PLUNGER	16 S 181
1240 304 278	T08949	336 264 0239	ZF 57	77	SYNCHRONIZER PRESSURE PLUNGER	16 S 221
1240 304 278	T08949	336 264 0239	ZF 58	78	SYNCHRONIZER PRESSURE PLUNGER	16 S 251
1246 304 278	T08874	000 262 2434	ZF 37	21	SYNCHRONIZER BLOCKING RING	16 S 112
1246 304 278	T08874	000 262 2434	ZF 41	21	SYNCHRONIZER BLOCKING RING	16 S 130
1246 304 278	T08874	000 262 2434	ZF 44	21	SYNCHRONIZER BLOCKING RING	16 S 160
1246 304 278	T08874	000 262 2434	ZF 47	21	SYNCHRONIZER BLOCKING RING	16 S 190
1257 304 020	T08946	336 262 0023	ZF 37	23	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 112
1257 304 020	T08946	336 262 0023	ZF 41	23	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 130
1257 304 020	T08946	336 262 0023	ZF 44	23	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 160
1257 304 020	T08946	336 262 0023	ZF 47	23	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 190
1268 304 424	T15059	000 262 2636	ZF 50	20	SYNCHRONIZER INTERNAL RING	16 S 150
1268 304 424	T15059	000 262 2636	ZF 51	20	SYNCHRONIZER INTERNAL RING	16 S 220
1268 304 424	T15059	000 262 2636	ZF 55	19	SYNCHRONIZER INTERNAL RING	16 S 151
1268 304 424	T15059	000 262 2636	ZF 56	19	SYNCHRONIZER INTERNAL RING	16 S 181
1268 304 424	T15059	000 262 2636	ZF 57	19	SYNCHRONIZER INTERNAL RING	16 S 221
1268 304 494	T15065	000 262 3436	ZF 50	21	SYNCHRONIZER INTERMEDIATE RING	16 S 150
1268 304 494	T15065	000 262 3436	ZF 51	21	SYNCHRONIZER INTERMEDIATE RING	16 S 220
1268 304 494	T15065	000 262 3436	ZF 55	20	SYNCHRONIZER INTERMEDIATE RING	16 S 151
1268 304 494	T15065	000 262 3436	ZF 56	20	SYNCHRONIZER INTERMEDIATE RING	16 S 181
1268 304 494	T15065	000 262 3436	ZF 57	20	SYNCHRONIZER INTERMEDIATE RING	16 S 221
1268 304 525	T15072	000 262 3934	ZF 50	22	SYNCHRONIZER BLOCKING RING	16 S 150
1268 304 525	T15072	000 262 3934	ZF 51	22	SYNCHRONIZER BLOCKING RING	16 S 220
1268 304 525	T15072	000 262 3934	ZF 55	21	SYNCHRONIZER BLOCKING RING	16 S 151
1268 304 525	T15072	000 262 3934	ZF 56	21	SYNCHRONIZER BLOCKING RING	16 S 181
1268 304 525	T15072	000 262 3934	ZF 57	21	SYNCHRONIZER BLOCKING RING	16 S 221
1269 202 087			ZF 37	38	MAIN DRIVE GEAR OIL PUMP	16 S 112
1269 202 087			ZF 40	32	MAIN DRIVE GEAR OIL PUMP	16 K 130
1269 202 087			ZF 41	38	MAIN DRIVE GEAR OIL PUMP	16 S 130
1269 202 087			ZF 43	34	MAIN DRIVE GEAR OIL PUMP	16 K 160
1269 202 087			ZF 44	39	MAIN DRIVE GEAR OIL PUMP	16 S 160
1269 202 087			ZF 46	35	MAIN DRIVE GEAR OIL PUMP	16 K 190
1269 332 036	T08919	000 264 1618	ZF 37	61	GEAR SHAFT	16 S 112
1269 332 036	T08919	000 264 1618	ZF 40	61	GEAR SHAFT	16 K 130
1269 332 036	T08919	000 264 1618	ZF 41	61	GEAR SHAFT	16 S 130
1295 202 004	T09793	001 262 1802	ZF 40	4	MAIN DRIVE GEAR (57T.)	16 K 130
1295 202 004	T09793	001 262 1802	ZF 41	4	MAIN DRIVE GEAR (57T.)	16 S 130
1295 202 005			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1295 202 006			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1295 202 007	T11210		ZF 40	4	MAIN DRIVE GEAR (57T.)	16 K 130
1295 202 007	T11210		ZF 41	4	MAIN DRIVE GEAR (57T.)	16 S 130
1295 202 008			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1295 202 011			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1295 202 012			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1295 202 013			ZF 40	4	MAIN DRIVE GEAR	16 K 130
1295 202 013			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1295 202 015			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1295 202 019			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1295 202 020			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1295 202 021			ZF 41	1	CONSTANT GEAR (28T.)	16 S 130
1295 202 022			ZF 41	1	CONSTANT GEAR (30T.)	16 S 130
1295 202 023			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1295 202 024			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1295 202 028	T11171	001 262 1902	ZF 41	4	MAIN DRIVE GEAR (57T.)	16 S 130
1295 202 035			ZF 37	38	MAIN DRIVE GEAR OIL PUMP	16 S 112
1295 202 035			ZF 40	32	MAIN DRIVE GEAR OIL PUMP	16 K 130
1295 202 035			ZF 41	38	MAIN DRIVE GEAR OIL PUMP	16 S 130
1295 202 035			ZF 43	34	MAIN DRIVE GEAR OIL PUMP	16 K 160
1295 202 035			ZF 44	39	MAIN DRIVE GEAR OIL PUMP	16 S 160
1295 202 035			ZF 46	35	MAIN DRIVE GEAR OIL PUMP	16 K 190
1295 202 035			ZF 47	39	MAIN DRIVE GEAR OIL PUMP	16 S 190

I riferimenti originali sono riportati solo come indicazione di particolari originali corrispondenti.
 All manufactures' names, numbers, symbols and descriptions are used for reference purposes only, and it is not implied that any part listed is the product of these manufacturers.

PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
1295 202 036			ZF 40	4	MAIN DRIVE GEAR	16 K 130
1295 202 036			ZF 41	5	MAIN DRIVE GEAR	16 S 130
1295 202 039			ZF 40	4	MAIN DRIVE GEAR	16 K 130
1295 202 039			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1295 202 041			ZF 37	38	MAIN DRIVE GEAR OIL PUMP	16 S 112
1295 202 041	T09751	000 260 1290	ZF 40	32	MAIN DRIVE GEAR OIL PUMP	16 K 130
1295 202 041	T09751	000 260 1290	ZF 41	38	MAIN DRIVE GEAR OIL PUMP	16 S 130
1295 202 041	T09751	000 260 1290	ZF 43	34	MAIN DRIVE GEAR OIL PUMP	16 K 160
1295 202 041	T09751	000 260 1290	ZF 44	39	MAIN DRIVE GEAR OIL PUMP	16 S 160
1295 202 041	T09751	000 260 1290	ZF 46	35	MAIN DRIVE GEAR OIL PUMP	16 K 190
1295 202 041	T09751	000 260 1290	ZF 47	39	MAIN DRIVE GEAR OIL PUMP	16 S 190
1295 202 041	T09751	000 260 1290	ZF 50	45	MAIN DRIVE GEAR OIL PUMP	16 S 150
1295 202 041	T09751	000 260 1290	ZF 51	45	MAIN DRIVE GEAR OIL PUMP	16 S 220
1295 202 044			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1295 202 045			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1295 202 054			ZF 40	32	MAIN DRIVE GEAR OIL PUMP	16 K 130
1295 202 054			ZF 41	38	MAIN DRIVE GEAR OIL PUMP	16 S 130
1295 202 054			ZF 43	34	MAIN DRIVE GEAR OIL PUMP	16 K 160
1295 202 054			ZF 44	39	MAIN DRIVE GEAR OIL PUMP	16 S 160
1295 202 054			ZF 46	35	MAIN DRIVE GEAR OIL PUMP	16 K 190
1295 202 054			ZF 47	39	MAIN DRIVE GEAR OIL PUMP	16 S 190
1295 202 054			ZF 50	45	MAIN DRIVE GEAR OIL PUMP	16 S 150
1295 202 054			ZF 51	45	MAIN DRIVE GEAR OIL PUMP	16 S 220
1295 202 056			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1295 202 057			ZF 46	35	MAIN DRIVE GEAR OIL PUMP	16 K 190
1295 202 057			ZF 47	39	MAIN DRIVE GEAR OIL PUMP	16 S 190
1295 202 057			ZF 51	45	MAIN DRIVE GEAR OIL PUMP	16 S 220
1295 202 087			ZF 47	39	MAIN DRIVE GEAR OIL PUMP	16 S 190
1295 202 100			ZF 44	38	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1295 204 005			ZF 41	17	THIRD SPEED GEAR (34T.)	16 S 130
1295 204 006			ZF 41	19	SECOND SPEED GEAR (38T.)	16 S 130
1295 204 007			ZF 41	24	FIRST SPEED GEAR (47T.)	16 S 130
1295 204 009			ZF 41	17	THIRD SPEED GEAR (32T.)	16 S 130
1295 204 011			ZF 41	24	FIRST SPEED GEAR (44T.)	16 S 130
1295 221 001			ZF 40	4	MAIN DRIVE GEAR	16 K 130
1295 221 001			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1295 221 002			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1295 221 003			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1295 221 008			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1295 232 027			ZF 37	68	GEAR SET (5 PCS.)	16 S 112
1295 232 027			ZF 40	68	GEAR SET (5 PCS.)	16 K 130
1295 232 027			ZF 41	68	GEAR SET (5 PCS.)	16 S 130
(1295 232 027/G)			ZF 37	67	GEAR	16 S 112
(1295 232 027/G)			ZF 40	67	GEAR	16 K 130
(1295 232 027/G)			ZF 41	67	GEAR	16 S 130
1295 232 028			ZF 37	60	CARRIER	16 S 112
1295 232 028			ZF 40	60	CARRIER	16 K 130
1295 232 028			ZF 41	60	CARRIER	16 S 130
1295 232 032			ZF 37	68	GEAR SET (5 PCS.)	16 S 112
(1295 232 032/G)			ZF 37	67	GEAR	16 S 112
1295 232 037			ZF 40	60	CARRIER	16 K 130
1295 232 038			ZF 40	68	GEAR SET (5 PCS.)	16 K 130
(1295 232 038/G)			ZF 40	67	GEAR	16 K 130
1295 232 044			ZF 37	60	CARRIER	16 S 112
1295 232 044			ZF 40	60	CARRIER	16 K 130
1295 232 044			ZF 41	60	CARRIER	16 S 130
1295 232 045			ZF 40	60	CARRIER	16 K 130
1295 232 048			ZF 37	60	CARRIER	16 S 112
1295 232 048			ZF 40	60	CARRIER	16 K 130
1295 232 048			ZF 41	60	CARRIER	16 S 130
1295 233 025	T09063	000 263 1920	ZF 37	78	SYNCHRONIZER CONE (63T.)	16 S 112
1295 233 025	T09063	000 263 1920	ZF 40	78	SYNCHRONIZER CONE (63T.)	16 K 130
1295 233 025	T09063	000 263 1920	ZF 41	78	SYNCHRONIZER CONE (63T.)	16 S 130
1295 238 003			ZF 37	79	CARRIER COUPLING FLANGE	16 S 112
1295 238 003			ZF 41	80	CARRIER COUPLING FLANGE	16 S 130
1295 302 070			ZF 40	1	CONSTANT GEAR (30T.)	16 K 130
1295 302 070			ZF 41	1	CONSTANT GEAR (30T.)	16 S 130
1295 302 071	T09771	000 262 4010	ZF 40	1	CONSTANT GEAR (28T.)	16 K 130
1295 302 071	T09771	000 262 4010	ZF 41	1	CONSTANT GEAR (28T.)	16 S 130
1295 302 074			ZF 41	1	CONSTANT GEAR (28T.)	16 S 130
1295 302 099			ZF 40	31	MAIN DRIVE GEAR BEARING RETAINER	16 K 130
1295 302 099			ZF 46	34	MAIN DRIVE GEAR BEARING RETAINER	16 K 190
1295 302 100			ZF 37	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 112
1295 302 100			ZF 41	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 130
1295 302 100			ZF 47	38	MAIN DRIVE GEAR BEARING RETAINER	16 S 190
1295 302 100			ZF 50	44	MAIN DRIVE GEAR BEARING RETAINER	16 S 150

PROGRESSIVE ORIGINAL REFERENCES



PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
1295 302 122			ZF 40	1	CONSTANT GEAR (29T.)	16 K 130
1295 302 122			ZF 41	1	CONSTANT GEAR (29T.)	16 S 130
1295 302 168			ZF 40	1	CONSTANT GEAR (29T.)	16 K 130
1295 302 168			ZF 41	1	CONSTANT GEAR (29T.)	16 S 130
1295 302 173			ZF 40	1	CONSTANT GEAR (28T.)	16 K 130
1295 302 173			ZF 41	1	CONSTANT GEAR (28T.)	16 S 130
1295 302 174			ZF 40	1	CONSTANT GEAR (30T.)	16 K 130
1295 303 005			ZF 40	26	COUNTERSHAFT THIRD SPEED GEAR (28T.)	16 K 130
1295 303 006			ZF 40	26	COUNTERSHAFT THIRD SPEED GEAR (25T.)	16 K 130
1295 303 025			ZF 41	31	COUNTERSHAFT THIRD SPEED GEAR (28T.)	16 S 130
1295 303 026	T09783	000 263 3510	ZF 41	31	COUNTERSHAFT THIRD SPEED GEAR (25T.)	16 S 130
1295 303 027	T09785	000 263 3610	ZF 40	25	COUNTERSHAFT FOURTH SPEED GEAR (31T.)	16 K 130
1295 303 027	T09785	000 263 3610	ZF 41	30	COUNTERSHAFT FOURTH SPEED GEAR (31T.)	16 S 130
1295 303 028			ZF 40	25	COUNTERSHAFT FOURTH SPEED GEAR (34T.)	16 K 130
1295 303 028			ZF 41	30	COUNTERSHAFT FOURTH SPEED GEAR (34T.)	16 S 130
1295 303 036	T09799	000 263 8410	ZF 40	24	COUNTERSHAFT CONSTANT GEAR (31T.)	16 K 130
1295 303 036	T09799	000 263 8410	ZF 41	29	COUNTERSHAFT CONSTANT GEAR (31T.)	16 S 130
1295 303 037	T09787	000 263 3710	ZF 41	29	COUNTERSHAFT CONSTANT GEAR (34T.)	16 S 130
1295 303 042			ZF 40	27	COUNTERSHAFT (19-23T.)	16 K 130
1295 303 045			ZF 41	32	COUNTERSHAFT (19-23T.)	16 S 130
1295 303 055			ZF 40	27	COUNTERSHAFT (17-20T.)	16 K 130
1295 303 056			ZF 40	27	COUNTERSHAFT (19-23T.)	16 K 130
1295 303 060			ZF 40	24	COUNTERSHAFT CONSTANT GEAR (32T.)	16 K 130
1295 303 060			ZF 41	29	COUNTERSHAFT CONSTANT GEAR (32T.)	16 S 130
1295 303 066	T09781	000 263 3402	ZF 41	32	COUNTERSHAFT (17-20T.)	16 S 130
1295 303 067			ZF 41	32	COUNTERSHAFT (19-23T.)	16 S 130
1295 303 071			ZF 41	31	COUNTERSHAFT THIRD SPEED GEAR (36T.)	16 S 130
1295 303 072			ZF 41	32	COUNTERSHAFT	16 S 130
1295 303 089			ZF 40	27	COUNTERSHAFT (19-23T.)	16 K 130
1295 303 091			ZF 41	31	COUNTERSHAFT THIRD SPEED GEAR (28T.)	16 S 130
1295 303 092			ZF 40	24	COUNTERSHAFT CONSTANT GEAR (32T.)	16 K 130
1295 303 092			ZF 41	29	COUNTERSHAFT CONSTANT GEAR (32T.)	16 S 130
1295 303 094			ZF 40	25	COUNTERSHAFT FOURTH SPEED GEAR (35T.)	16 K 130
1295 303 094			ZF 41	30	COUNTERSHAFT FOURTH SPEED GEAR (35T.)	16 S 130
1295 303 101			ZF 40	24	COUNTERSHAFT CONSTANT GEAR (34T.)	16 K 130
1295 303 101			ZF 41	29	COUNTERSHAFT CONSTANT GEAR (34T.)	16 S 130
1295 303 102			ZF 40	24	COUNTERSHAFT CONSTANT GEAR (31T.)	16 K 130
1295 303 103			ZF 41	30	COUNTERSHAFT FOURTH SPEED GEAR (31T.)	16 S 130
1295 303 104			ZF 40	25	COUNTERSHAFT FOURTH SPEED GEAR (34T.)	16 K 130
1295 303 105			ZF 41	31	COUNTERSHAFT THIRD SPEED GEAR (25T.)	16 S 130
1295 304 002	T09056	000 262 3623	ZF 37	11	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 112
1295 304 002	T09056	000 262 3623	ZF 37	16	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 112
1295 304 002	T09056	000 262 3623	ZF 37	23	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 112
1295 304 002	T09056	000 262 3623	ZF 40	10	SYNCHRONIZER SLIDING COLLAR (57T.)	16 K 130
1295 304 002	T09056	000 262 3623	ZF 41	11	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 130
1295 304 002	T09056	000 262 3623	ZF 41	16	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 130
1295 304 002	T09056	000 262 3623	ZF 41	23	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 130
1295 304 002	T09056	000 262 3623	ZF 43	10	SYNCHRONIZER SLIDING COLLAR (57T.)	16 K 160
1295 304 002	T09056	000 262 3623	ZF 44	11	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 160
1295 304 002	T09056	000 262 3623	ZF 44	16	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 160
1295 304 002	T09056	000 262 3623	ZF 46	11	SYNCHRONIZER SLIDING COLLAR (57T.)	16 K 190
1295 304 002	T09056	000 262 3623	ZF 47	11	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 190
1295 304 002	T09056	000 262 3623	ZF 47	16	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 190
1295 304 004	T08795	000 262 2034	ZF 37	3	SYNCHRONIZER BLOCKING RING	16 S 112
1295 304 004	T08795	000 262 2034	ZF 37	14	SYNCHRONIZER BLOCKING RING	16 S 112
1295 304 004	T08795	000 262 2034	ZF 37	21	SYNCHRONIZER BLOCKING RING	16 S 112
1295 304 004	T08795	000 262 2034	ZF 40	3	SYNCHRONIZER BLOCKING RING	16 K 130
1295 304 004	T08795	000 262 2034	ZF 41	3	SYNCHRONIZER BLOCKING RING	16 S 130
1295 304 004	T08795	000 262 2034	ZF 41	14	SYNCHRONIZER BLOCKING RING	16 S 130
1295 304 004	T08795	000 262 2034	ZF 41	21	SYNCHRONIZER BLOCKING RING	16 S 130
1295 304 004	T08795	000 262 2034	ZF 43	3	SYNCHRONIZER BLOCKING RING	16 K 160
1295 304 004	T08795	000 262 2034	ZF 44	3	SYNCHRONIZER BLOCKING RING	16 S 160
1295 304 004	T08795	000 262 2034	ZF 44	14	SYNCHRONIZER BLOCKING RING	16 S 160
1295 304 004	T08795	000 262 2034	ZF 46	3	SYNCHRONIZER BLOCKING RING	16 K 190
1295 304 004	T08795	000 262 2034	ZF 47	3	SYNCHRONIZER BLOCKING RING	16 S 190
1295 304 004	T08795	000 262 2034	ZF 47	14	SYNCHRONIZER BLOCKING RING	16 S 190
1295 304 010			ZF 41	19	SECOND SPEED GEAR (37T.)	16 S 130
1295 304 012			ZF 37	26	REVERSE GEAR SLEEVE	16 S 112
1295 304 012			ZF 40	21	REVERSE GEAR SLEEVE	16 K 130
1295 304 012			ZF 41	26	REVERSE GEAR SLEEVE	16 S 130
1295 304 024			ZF 40	20	FIRST SPEED AND REVERSE GEAR CONE	16 K 130
1295 304 024			ZF 41	25	FIRST SPEED AND REVERSE GEAR CONE	16 S 130
1295 304 026			ZF 37	25	FIRST SPEED AND REVERSE GEAR CONE	16 S 112
1295 304 115			ZF 40	22	REVERSE GEAR (39T.)	16 K 130
1295 304 115			ZF 41	27	REVERSE GEAR (39T.)	16 S 130
1295 304 120			ZF 41	19	SECOND SPEED GEAR (37T.)	16 S 130

I riferimenti originali sono riportati solo come indicazione di particolari originali corrispondenti.
 All manufactures' names, numbers, symbols and descriptions are used for reference purposes only, and it is not implied that any part listed is the product of these manufacturers.

PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
1295 304 121			ZF 41	19	SECOND SPEED GEAR (38T.)	16 S 130
1295 304 123			ZF 41	24	FIRST SPEED GEAR (44T.)	16 S 130
1295 304 127			ZF 41	17	THIRD SPEED GEAR (32T.)	16 S 130
1295 304 128	T11158	000 262 3213	ZF 41	17	THIRD SPEED GEAR (34T.)	16 S 130
1295 304 135	T09759	000 262 2514	ZF 41	12	FOURTH SPEED GEAR (30T.)	16 S 130
1295 304 136			ZF 41	12	FOURTH SPEED GEAR (28T.)	16 S 130
1295 304 165	T08858	000 262 1440	ZF 37	2	SYNCHRONIZER CONE (57T.)	16 S 112
1295 304 165	T08858	000 262 1440	ZF 41	2	SYNCHRONIZER CONE (57T.)	16 S 130
1295 304 165	T08858	000 262 1440	ZF 44	2	SYNCHRONIZER CONE (57T.)	16 S 160
1295 304 178			ZF 40	18	FIRST AND SECOND SPEED SLIDING COLLAR	16 K 130
1295 304 179			ZF 40	13	THIRD AND FOURTH SPEED SLIDING COLLAR	16 K 130
1295 304 181			ZF 40	11	FOURTH SPEED GEAR (28T.)	16 K 130
1295 304 182			ZF 40	11	FOURTH SPEED GEAR (30T.)	16 K 130
1295 304 184			ZF 40	16	SECOND SPEED GEAR (38T.)	16 K 130
1295 304 185			ZF 40	16	SECOND SPEED GEAR (37T.)	16 K 130
1295 304 187			ZF 40	14	THIRD SPEED GEAR (34T.)	16 K 130
1295 304 188			ZF 40	14	THIRD SPEED GEAR (32T.)	16 K 130
1295 304 194			ZF 40	19	FIRST SPEED GEAR (44T.)	16 K 130
1295 304 200			ZF 40	22	REVERSE GEAR (38T.)	16 K 130
1295 304 200			ZF 41	27	REVERSE GEAR (38T.)	16 S 130
1295 304 201			ZF 40	22	REVERSE GEAR (39T.)	16 K 130
1295 304 201			ZF 41	27	REVERSE GEAR (39T.)	16 S 130
1295 304 202			ZF 41	24	FIRST SPEED GEAR (47T.)	16 S 130
1295 304 203			ZF 41	24	FIRST SPEED GEAR (44T.)	16 S 130
1295 304 204			ZF 40	19	FIRST SPEED GEAR (44T.)	16 K 130
1295 304 205			ZF 40	19	FIRST SPEED GEAR (47T.)	16 K 130
1295 304 206			ZF 40	20	FIRST SPEED AND REVERSE GEAR CONE	16 K 130
1295 304 206			ZF 41	25	FIRST SPEED AND REVERSE GEAR CONE	16 S 130
1295 304 234			ZF 40	12	THIRD AND FOURTH SPEED CLUTCH GEAR	16 K 130
1295 304 235	T09753	000 262 2127	ZF 40	17	FIRST AND SECOND SPEED CLUTCH GEAR	16 K 130
1295 304 235	T09753	000 262 2127	ZF 43	17	FIRST AND SECOND SPEED CLUTCH GEAR	16 K 160
1295 304 235	T09753	000 262 2127	ZF 46	18	FIRST AND SECOND SPEED CLUTCH GEAR	16 K 190
1295 304 236			ZF 41	12	FOURTH SPEED GEAR (26T.)	16 S 130
1295 304 243			ZF 40	15	MAINSHAFT	16 K 130
1295 304 245	T09763	000 262 2605	ZF 41	18	MAINSHAFT	16 S 130
1295 304 247			ZF 37	28	PLANETARY REDUCTION SUN GEAR (27T.)	16 S 112
1295 304 247			ZF 40	23	PLANETARY REDUCTION SUN GEAR (27T.)	16 K 130
1295 304 248			ZF 41	28	PLANETARY REDUCTION SUN GEAR (27T.)	16 S 130
1295 304 250			ZF 41	18	MAINSHAFT	16 S 130
1295 304 251			ZF 40	23	PLANETARY REDUCTION SUN GEAR (24T.)	16 K 130
1295 304 251			ZF 41	28	PLANETARY REDUCTION SUN GEAR (24T.)	16 S 130
1295 304 263			ZF 41	26	REVERSE GEAR SLEEVE	16 S 130
1295 304 269			ZF 41	17	THIRD SPEED GEAR (25T.)	16 S 130
1295 304 270			ZF 41	24	FIRST SPEED GEAR (41T.)	16 S 130
1295 304 272			ZF 41	27	REVERSE GEAR (39T.)	16 S 130
1295 304 273			ZF 41	18	MAINSHAFT	16 S 130
1295 304 278	T08871	000 262 1940	ZF 37	2	SYNCHRONIZER CONE (57T.)	16 S 112
1295 304 278	T08871	000 262 1940	ZF 37	13	SYNCHRONIZER CONE (57T.)	16 S 112
1295 304 278	T08871	000 262 1940	ZF 37	20	SYNCHRONIZER CONE (57T.)	16 S 112
1295 304 278	T08871	000 262 1940	ZF 40	2	SYNCHRONIZER CONE (57T.)	16 K 130
1295 304 278	T08871	000 262 1940	ZF 41	2	SYNCHRONIZER CONE (57T.)	16 S 130
1295 304 278	T08871	000 262 1940	ZF 41	13	SYNCHRONIZER CONE (57T.)	16 S 130
1295 304 278	T08871	000 262 1940	ZF 41	20	SYNCHRONIZER CONE (57T.)	16 S 130
1295 304 278	T08871	000 262 1940	ZF 43	2	SYNCHRONIZER CONE (57T.)	16 K 160
1295 304 278	T08871	000 262 1940	ZF 44	2	SYNCHRONIZER CONE (57T.)	16 S 160
1295 304 278	T08871	000 262 1940	ZF 44	13	SYNCHRONIZER CONE (57T.)	16 S 160
1295 304 278	T08871	000 262 1940	ZF 46	2	SYNCHRONIZER CONE (57T.)	16 K 190
1295 304 278	T08871	000 262 1940	ZF 47	2	SYNCHRONIZER CONE (57T.)	16 S 190
1295 304 278	T08871	000 262 1940	ZF 47	13	SYNCHRONIZER CONE (57T.)	16 S 190
1295 304 303			ZF 40	11	FOURTH SPEED GEAR (26T.)	16 K 130
1295 304 304			ZF 40	15	MAINSHAFT	16 K 130
1295 304 305			ZF 41	19	SECOND SPEED GEAR (37T.)	16 S 130
1295 304 306			ZF 41	24	FIRST SPEED GEAR (44T.)	16 S 130
1295 304 307			ZF 41	17	THIRD SPEED GEAR (32T.)	16 S 130
1295 304 322			ZF 41	12	FOURTH SPEED GEAR (30T.)	16 S 130
1295 304 324			ZF 41	17	THIRD SPEED GEAR (34T.)	16 S 130
1295 305 051			ZF 37	34	REVERSE IDLER GEAR (21T.)	16 S 112
1295 305 051			ZF 40	29	REVERSE IDLER GEAR (21T.)	16 K 130
1295 305 051			ZF 41	34	REVERSE IDLER GEAR (21T.)	16 S 130
1295 305 051			ZF 43	30	REVERSE IDLER GEAR (21T.)	16 K 160
1295 305 051			ZF 44	35	REVERSE IDLER GEAR	16 S 160
1295 305 051			ZF 46	31	REVERSE IDLER GEAR (21T.)	16 K 190
1295 305 051			ZF 47	35	REVERSE IDLER GEAR (21T.)	16 S 190
1295 305 052			ZF 37	34	REVERSE IDLER GEAR (24T.)	16 S 112
1295 305 052			ZF 40	29	REVERSE IDLER GEAR (24T.)	16 K 130
1295 305 052			ZF 41	34	REVERSE IDLER GEAR (24T.)	16 S 130

PROGRESSIVE ORIGINAL REFERENCES



PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
1295 305 052			ZF 43	30	REVERSE IDLER GEAR (24T.)	16 K 160
1295 305 052			ZF 44	35	REVERSE IDLER GEAR	16 S 160
1295 305 052			ZF 46	31	REVERSE IDLER GEAR (24T.)	16 K 190
1295 305 052			ZF 47	35	REVERSE IDLER GEAR (24T.)	16 S 190
1295 305 056	T11447	000 263 1430	ZF 37	33	REVERSE IDLER GEAR SHAFT	16 S 112
1295 305 056	T11447	000 263 1430	ZF 40	28	REVERSE IDLER GEAR SHAFT	16 K 130
1295 305 056	T11447	000 263 1430	ZF 41	33	REVERSE IDLER GEAR SHAFT	16 S 130
1295 305 056	T11447	000 263 1430	ZF 43	29	REVERSE IDLER GEAR SHAFT	16 K 160
1295 305 056	T11447	000 263 1430	ZF 44	34	REVERSE IDLER GEAR SHAFT	16 S 160
1295 305 056	T11447	000 263 1430	ZF 46	30	REVERSE IDLER GEAR SHAFT	16 K 190
1295 305 056	T11447	000 263 1430	ZF 47	34	REVERSE IDLER GEAR SHAFT	16 S 190
1295 305 056	T11447	000 263 1430	ZF 50	40	REVERSE IDLER GEAR SHAFT	16 S 150
1295 305 056	T11447	000 263 1430	ZF 51	40	REVERSE IDLER GEAR SHAFT	16 S 220
1295 306 132	T08933	000 268 0849	ZF 37	90	SLIDING BLOCK (BRONZE)	16 S 112
1295 306 132	T08933	000 268 0849	ZF 40	90	SLIDING BLOCK (BRONZE)	16 K 130
1295 306 132	T08933	000 268 0849	ZF 41	90	SLIDING BLOCK (BRONZE)	16 S 130
1295 306 132	T08933	000 268 0849	ZF 43	90	SLIDING BLOCK (BRONZE)	16 K 160
1295 306 132	T08933	000 268 0849	ZF 44	90	SLIDING BLOCK (BRONZE)	16 S 160
1295 306 132	T08933	000 268 0849	ZF 46	90	SLIDING BLOCK (BRONZE)	16 K 190
1295 306 132	T08933	000 268 0849	ZF 47	90	SLIDING BLOCK (BRONZE)	16 S 190
1295 332 021			ZF 37	70	RING GEAR CARRIER (83T.)	16 S 112
1295 332 021			ZF 40	70	RING GEAR CARRIER (83T.)	16 K 130
1295 332 021			ZF 41	70	RING GEAR CARRIER (83T.)	16 S 130
1295 332 053			ZF 37	69	RING GEAR (83T.)	16 S 112
1295 332 053			ZF 40	69	RING GEAR (83T.)	16 K 130
1295 332 053			ZF 41	69	RING GEAR (83T.)	16 S 130
1295 332 084			ZF 40	70	RING GEAR CARRIER (86T.)	16 K 130
1295 332 086			ZF 40	69	RING GEAR (86T.)	16 K 130
1295 332 086			ZF 41	69	RING GEAR (86T.)	16 S 130
1295 332 086			ZF 43	69	RING GEAR (86T.)	16 K 160
1295 332 086			ZF 44	69	RING GEAR (86T.)	16 S 160
1295 332 086			ZF 46	69	RING GEAR (86T.)	16 K 190
1295 332 086			ZF 47	69	RING GEAR (86T.)	16 S 190
1295 332 086			ZF 50	69	RING GEAR (86T.)	16 S 150
1295 332 086			ZF 51	69	RING GEAR (86T.)	16 S 220
1295 332 086			ZF 55	69	RING GEAR (86T.)	16 S 151
1295 332 086			ZF 57	70	RING GEAR (86T.)	16 S 221
1295 338 014			ZF 37	79	CARRIER COUPLING FLANGE	16 S 112
1295 338 014			ZF 40	79	CARRIER COUPLING FLANGE	16 K 130
1295 338 014			ZF 41	80	CARRIER COUPLING FLANGE	16 S 130
1295 338 017			ZF 41	80	CARRIER COUPLING FLANGE (38 SPLINES)	16 S 130
1295 338 028			ZF 41	80	CARRIER COUPLING FLANGE	16 S 130
1295 338 059	T14811	000 264 3745	ZF 37	79	CARRIER COUPLING FLANGE	16 S 112
1295 338 059	T14811	000 264 3745	ZF 41	80	CARRIER COUPLING FLANGE	16 S 130
1295 338 061			ZF 37	79	CARRIER COUPLING FLANGE	16 S 112
1295 338 061			ZF 40	79	CARRIER COUPLING FLANGE	16 K 130
1295 338 061			ZF 41	80	CARRIER COUPLING FLANGE	16 S 130
1295 338 147			ZF 41	80	CARRIER COUPLING FLANGE	16 S 130
1296 202 001	T11173	001 262 2002	ZF 37	4	MAIN DRIVE GEAR (57T.)	16 S 112
1296 202 004	T15119	000 262 9402	ZF 37	4	MAIN DRIVE GEAR	16 S 112
1296 202 006			ZF 37	4	MAIN DRIVE GEAR	16 S 112
1296 202 010			ZF 37	4	MAIN DRIVE GEAR	16 S 112
1296 202 011			ZF 37	5	MAIN DRIVE GEAR	16 S 112
1296 221 001			ZF 37	4	MAIN DRIVE GEAR	16 S 112
1296 221 002			ZF 37	4	MAIN DRIVE GEAR	16 S 112
1296 232 002			ZF 50	60	CARRIER	16 S 150
1296 232 002			ZF 55	60	CARRIER	16 S 151
1296 233 006	T08908	000 263 1720	ZF 37	71	SYNCHRONIZER FLANGE WITH CONE (63T.)	16 S 112
1296 233 006	T08908	000 263 1720	ZF 40	71	SYNCHRONIZER FLANGE WITH CONE (63T.)	16 K 130
1296 233 006	T08908	000 263 1720	ZF 41	71	SYNCHRONIZER FLANGE WITH CONE (63T.)	16 S 130
1296 233 006	T08908	000 263 1720	ZF 43	71	SYNCHRONIZER FLANGE WITH CONE (63T.)	16 K 160
1296 233 006	T08908	000 263 1720	ZF 44	71	SYNCHRONIZER FLANGE WITH CONE (63T.)	16 S 160
1296 233 006	T08908	000 263 1720	ZF 46	71	SYNCHRONIZER FLANGE WITH CONE (63T.)	16 K 190
1296 233 006	T08908	000 263 1720	ZF 47	71	SYNCHRONIZER FLANGE WITH CONE (63T.)	16 S 190
1296 233 006	T08908	000 263 1720	ZF 50	71	SYNCHRONIZER FLANGE WITH CONE (63T.)	16 S 150
1296 233 006	T08908	000 263 1720	ZF 51	71	SYNCHRONIZER FLANGE WITH CONE (63T.)	16 S 220
1296 302 002			ZF 37	1	CONSTANT GEAR (30T.)	16 S 112
1296 302 003	T11161	000 262 3910	ZF 37	1	CONSTANT GEAR (28T.)	16 S 112
1296 302 023	T14807	000 262 3010	ZF 37	1	CONSTANT GEAR (28T.)	16 S 112
1296 303 002	T11169	000 263 3310	ZF 37	30	COUNTERSHAFT FOURTH SPEED GEAR (31T.)	16 S 112
1296 303 003			ZF 37	30	COUNTERSHAFT FOURTH SPEED GEAR (34T.)	16 S 112
1296 303 008			ZF 37	31	COUNTERSHAFT THIRD SPEED GEAR (28T.)	16 S 112
1296 303 009	T11163	000 263 3110	ZF 37	31	COUNTERSHAFT THIRD SPEED GEAR (25T.)	16 S 112
1296 303 013			ZF 37	29	COUNTERSHAFT CONSTANT GEAR (31T.)	16 S 112
1296 303 014	T11165	000 263 3210	ZF 37	29	COUNTERSHAFT CONSTANT GEAR (34T.)	16 S 112
1296 303 025			ZF 37	32	COUNTERSHAFT (17-20T.)	16 S 112

I riferimenti originali sono riportati solo come indicazione di particolari originali corrispondenti.
 All manufactures' names, numbers, symbols and descriptions are used for reference purposes only, and it is not implied that any part listed is the product of these manufacturers.



PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
1296 303 026			ZF 37	32	COUNTERSHAFT (19-23T.)	16 S 112
1296 303 035			ZF 50	37	COUNTERSHAFT THIRD SPEED GEAR (26T.)	16 S 150
1296 303 036			ZF 50	36	COUNTERSHAFT FOURTH SPEED GEAR (37T.)	16 S 150
1296 303 037			ZF 50	35	COUNTERSHAFT CONSTANT GEAR (39T.)	16 S 150
1296 304 070			ZF 37	19	SECOND SPEED GEAR (38T.)	16 S 112
1296 304 071			ZF 37	19	SECOND SPEED GEAR (37T.)	16 S 112
1296 304 087	T11156	000 262 3113	ZF 37	17	THIRD SPEED GEAR (34T.)	16 S 112
1296 304 088			ZF 37	17	THIRD SPEED GEAR (32T.)	16 S 112
1296 304 090	T11154	000 262 2414	ZF 37	12	FOURTH SPEED GEAR (30T.)	16 S 112
1296 304 091			ZF 37	12	FOURTH SPEED GEAR (28T.)	16 S 112
1296 304 097			ZF 37	27	REVERSE GEAR (38T.)	16 S 112
1296 304 098			ZF 37	27	REVERSE GEAR (39T.)	16 S 112
1296 304 099			ZF 37	24	FIRST SPEED GEAR (47T.)	16 S 112
1296 304 100			ZF 37	24	FIRST SPEED GEAR (44T.)	16 S 112
1296 304 119			ZF 37	18	MAINSHAFT	16 S 112
1296 304 131			ZF 50	11	FOURTH SPEED GEAR (34T.)	16 S 150
1296 304 135	T08874	000 262 3734	ZF 37	21	SYNCHRONIZER BLOCKING RING	16 S 112
1296 304 135	T08874	000 262 3734	ZF 41	21	SYNCHRONIZER BLOCKING RING	16 S 130
1296 304 135	T08874	000 262 3734	ZF 44	21	SYNCHRONIZER BLOCKING RING	16 S 160
1296 304 135	T08874	000 262 3734	ZF 47	21	SYNCHRONIZER BLOCKING RING	16 S 190
1296 332 005			ZF 50	61	GEAR SHAFT	16 S 150
1296 332 005			ZF 55	61	GEAR SHAFT	16 S 151
1296 333 002	T08899	000 263 0735	ZF 37	73	SYNCHRONIZER HUB	16 S 112
1296 333 002	T08899	000 263 0735	ZF 40	73	SYNCHRONIZER HUB	16 K 130
1296 333 002	T08899	000 263 0735	ZF 41	73	SYNCHRONIZER HUB	16 S 130
1296 333 002	T08899	000 263 0735	ZF 43	73	SYNCHRONIZER HUB	16 K 160
1296 333 002	T08899	000 263 0735	ZF 44	73	SYNCHRONIZER HUB	16 S 160
1296 333 002	T08899	000 263 0735	ZF 46	73	SYNCHRONIZER HUB	16 K 190
1296 333 002	T08899	000 263 0735	ZF 47	73	SYNCHRONIZER HUB	16 S 190
1296 333 022	T09061	000 263 0234	ZF 37	72	SYNCHRONIZER BLOCKING RING	16 S 112
1296 333 022	T09061	000 263 0234	ZF 40	72	SYNCHRONIZER BLOCKING RING	16 K 130
1296 333 022	T09061	000 263 0234	ZF 41	72	SYNCHRONIZER BLOCKING RING	16 S 130
1296 333 022	T09061	000 263 0234	ZF 43	72	SYNCHRONIZER BLOCKING RING	16 K 160
1296 333 022	T09061	000 263 0234	ZF 44	72	SYNCHRONIZER BLOCKING RING	16 S 160
1296 333 022	T09061	000 263 0234	ZF 46	72	SYNCHRONIZER BLOCKING RING	16 K 190
1296 333 022	T09061	000 263 0234	ZF 47	72	SYNCHRONIZER BLOCKING RING	16 S 190
1296 333 022	T09061	000 263 0234	ZF 50	72	SYNCHRONIZER BLOCKING RING	16 S 150
1296 333 022	T09061	000 263 0234	ZF 51	72	SYNCHRONIZER BLOCKING RING	16 S 220
1296 333 022	T09061	000 263 0234	ZF 55	72	SYNCHRONIZER BLOCKING RING	16 S 151
1296 333 022	T09061	000 263 0234	ZF 55	79	SYNCHRONIZER BLOCKING RING	16 S 151
1296 333 022	T09061	000 263 0234	ZF 56	73	SYNCHRONIZER BLOCKING RING	16 S 181
1296 333 022	T09061	000 263 0234	ZF 58	74	SYNCHRONIZER BLOCKING RING	16 S 251
1296 333 023	T09062	000 263 0523	ZF 37	77	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 112
1296 333 023	T09062	000 263 0523	ZF 40	77	SYNCHRONIZER SLIDING COLLAR (63T.)	16 K 130
1296 333 023	T09062	000 263 0523	ZF 41	77	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 130
1296 333 023	T09062	000 263 0523	ZF 43	77	SYNCHRONIZER SLIDING COLLAR (63T.)	16 K 160
1296 333 023	T09062	000 263 0523	ZF 44	77	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 160
1296 333 023	T09062	000 263 0523	ZF 46	77	SYNCHRONIZER SLIDING COLLAR (63T.)	16 K 190
1296 333 023	T09062	000 263 0523	ZF 47	77	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 190
1296 333 023	T09062	000 263 0523	ZF 50	77	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 150
1296 333 023	T09062	000 263 0523	ZF 51	77	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 220
1296 333 023	T09062	000 263 0523	ZF 55	77	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 151
1296 333 023	T09062	000 263 0523	ZF 55	81	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 151
1296 333 023	T09062	000 263 0523	ZF 56	78	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 181
1296 333 023	T09062	000 263 0523	ZF 57	78	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 221
1296 333 023	T09062	000 263 0523	ZF 57	83	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 221
1296 333 023	T09062	000 263 0523	ZF 58	79	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 251
1296 333 044			ZF 37	72	SYNCHRONIZER BLOCKING RING	16 S 112
1296 333 044			ZF 40	72	SYNCHRONIZER BLOCKING RING	16 K 130
1296 333 044			ZF 41	72	SYNCHRONIZER BLOCKING RING	16 S 130
1296 333 044			ZF 43	72	SYNCHRONIZER BLOCKING RING	16 K 160
1296 333 044			ZF 44	72	SYNCHRONIZER BLOCKING RING	16 S 160
1296 333 044			ZF 46	72	SYNCHRONIZER BLOCKING RING	16 K 190
1296 333 044			ZF 47	72	SYNCHRONIZER BLOCKING RING	16 S 190
1296 333 044			ZF 50	72	SYNCHRONIZER BLOCKING RING	16 S 150
1296 333 044			ZF 51	72	SYNCHRONIZER BLOCKING RING	16 S 220
1296 333 044			ZF 55	72	SYNCHRONIZER BLOCKING RING	16 S 151
1296 333 044			ZF 55	79	SYNCHRONIZER BLOCKING RING	16 S 151
1296 333 044			ZF 56	73	SYNCHRONIZER BLOCKING RING	16 S 181
1296 333 044			ZF 57	73	SYNCHRONIZER BLOCKING RING	16 S 221
1296 333 044			ZF 57	81	SYNCHRONIZER BLOCKING RING	16 S 221
1296 333 044			ZF 58	74	SYNCHRONIZER BLOCKING RING	16 S 251
1296 333 045	T15084	000 263 0534	ZF 37	72	SYNCHRONIZER BLOCKING RING	16 S 112
1296 333 045	T15084	000 263 0534	ZF 40	72	SYNCHRONIZER BLOCKING RING	16 K 130
1296 333 045	T15084	000 263 0534	ZF 41	72	SYNCHRONIZER BLOCKING RING	16 S 130
1296 333 045	T15084	000 263 0534	ZF 43	72	SYNCHRONIZER BLOCKING RING	16 K 160

PROGRESSIVE ORIGINAL REFERENCES



PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
1296 333 045	T15084	000 263 0534	ZF 44	72	SYNCHRONIZER BLOCKING RING	16 S 160
1296 333 045	T15084	000 263 0534	ZF 46	72	SYNCHRONIZER BLOCKING RING	16 K 190
1296 333 045	T15084	000 263 0534	ZF 47	72	SYNCHRONIZER BLOCKING RING	16 S 190
1296 333 045	T15084	000 263 0534	ZF 50	72	SYNCHRONIZER BLOCKING RING	16 S 150
1296 333 045	T15084	000 263 0534	ZF 51	72	SYNCHRONIZER BLOCKING RING	16 S 220
1296 333 045	T15084	000 263 0534	ZF 55	72	SYNCHRONIZER BLOCKING RING	16 S 151
1296 333 045	T15084	000 263 0534	ZF 55	79	SYNCHRONIZER BLOCKING RING	16 S 151
1296 333 045	T15084	000 263 0534	ZF 56	73	SYNCHRONIZER BLOCKING RING	16 S 181
1296 333 045	T15084	000 263 0534	ZF 57	73	SYNCHRONIZER BLOCKING RING	16 S 221
1296 333 045	T15084	000 263 0534	ZF 57	81	SYNCHRONIZER BLOCKING RING	16 S 221
1296 333 045	T15084	000 263 0534	ZF 58	74	SYNCHRONIZER BLOCKING RING	16 S 251
1296 333 046			ZF 55	71	SYNCHRONIZER FLANGE	16 S 151
1296 333 046			ZF 56	71	SYNCHRONIZER FLANGE	16 S 181
1296 333 046			ZF 57	72	SYNCHRONIZER FLANGE WITH CONE	16 S 221
1296 333 050			ZF 55	78	SYNCHRONIZER CONE	16 S 151
1296 333 050			ZF 56	72	SYNCHRONIZER CONE	16 S 181
1296 333 050			ZF 57	80	SYNCHRONIZER CONE	16 S 221
1296 333 050			ZF 58	73	SYNCHRONIZER CONE	16 S 251
1296 334 004			ZF 37	91	SLIDING BLOCK	16 S 112
1296 334 004			ZF 40	91	SLIDING BLOCK	16 K 130
1296 334 004			ZF 41	91	SLIDING BLOCK	16 S 130
1296 334 004			ZF 43	91	SLIDING BLOCK	16 K 160
1296 334 004			ZF 44	91	SLIDING BLOCK	16 S 160
1296 334 004			ZF 46	91	SLIDING BLOCK	16 K 190
1296 334 004			ZF 47	91	SLIDING BLOCK	16 S 190
1296 334 004			ZF 50	91	SLIDING BLOCK	16 S 150
1296 334 004			ZF 51	91	SLIDING BLOCK	16 S 220
1296 334 004			ZF 55	91	SLIDING BLOCK	16 S 151
1296 334 004			ZF 56	91	SLIDING BLOCK	16 S 181
1296 334 004			ZF 57	91	SLIDING BLOCK	16 S 221
1296 334 004			ZF 58	91	SLIDING BLOCK	16 S 251
1297 202 003			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 202 003			ZF 47	4	MAIN DRIVE GEAR	16 S 190
1297 202 004			ZF 43	4	MAIN DRIVE GEAR	16 K 160
1297 202 004			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 202 004			ZF 47	4	MAIN DRIVE GEAR	16 S 190
1297 202 008			ZF 43	4	MAIN DRIVE GEAR	16 K 160
1297 202 008			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 202 009			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 202 009			ZF 47	4	MAIN DRIVE GEAR	16 S 190
1297 202 011			ZF 43	4	MAIN DRIVE GEAR	16 K 160
1297 202 011			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 202 011			ZF 47	4	MAIN DRIVE GEAR	16 S 190
1297 202 014			ZF 43	4	MAIN DRIVE GEAR	16 K 160
1297 202 014			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 202 030	T09791	001 262 0302	ZF 44	4	MAIN DRIVE GEAR (57T.)	16 S 160
1297 202 044			ZF 44	5	MAIN DRIVE GEAR	16 S 160
1297 202 044			ZF 46	5	MAIN DRIVE GEAR	16 K 190
1297 202 044			ZF 47	5	MAIN DRIVE GEAR	16 S 190
1297 202 045			ZF 43	4	MAIN DRIVE GEAR	16 K 160
1297 202 045			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 202 045			ZF 47	4	MAIN DRIVE GEAR	16 S 190
1297 202 046			ZF 43	4	MAIN DRIVE GEAR	16 K 160
1297 202 046			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 202 047			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 202 047			ZF 46	4	MAIN DRIVE GEAR	16 K 190
1297 202 048			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 202 049			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 202 049			ZF 47	4	MAIN DRIVE GEAR	16 S 190
1297 202 051			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 202 052			ZF 43	4	MAIN DRIVE GEAR	16 K 160
1297 202 052			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 202 053	T15053	001 262 2802	ZF 43	4	MAIN DRIVE GEAR (57T.)	16 K 160
1297 202 053	T15053	001 262 2802	ZF 44	4	MAIN DRIVE GEAR (57T.)	16 S 160
1297 202 053	T15053	001 262 2802	ZF 46	4	MAIN DRIVE GEAR (57T.)	16 K 190
1297 202 053	T15053	001 262 2802	ZF 47	4	MAIN DRIVE GEAR (57T.)	16 S 190
1297 202 054			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 202 054			ZF 47	4	MAIN DRIVE GEAR	16 S 190
1297 202 061			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 202 061			ZF 47	4	MAIN DRIVE GEAR	16 S 190
1297 202 062			ZF 43	4	MAIN DRIVE GEAR	16 K 160
1297 202 062			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 202 063			ZF 43	4	MAIN DRIVE GEAR	16 K 160
1297 202 063			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 202 063			ZF 47	4	MAIN DRIVE GEAR	16 S 190
1297 202 064			ZF 44	4	MAIN DRIVE GEAR	16 S 160

I riferimenti originali sono riportati solo come indicazione di particolari originali corrispondenti.
 All manufactures' names, numbers, symbols and descriptions are used for reference purposes only, and it is not implied that any part listed is the product of these manufacturers.

PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
1297 202 066			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 202 067			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1297 202 067			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 202 069			ZF 37	4	MAIN DRIVE GEAR	16 S 112
1297 202 069			ZF 47	4	MAIN DRIVE GEAR	16 S 190
1297 221 006			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1297 221 006			ZF 43	4	MAIN DRIVE GEAR	16 K 160
1297 221 006			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 221 008			ZF 41	4	MAIN DRIVE GEAR	16 S 130
1297 221 008			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 221 009			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 221 010			ZF 44	4	MAIN DRIVE GEAR	16 S 160
1297 232 023	T10131	000 260 1597	ZF 43	68	GEAR SET (26T.) (5 PCS.)	16 K 160
1297 232 023	T10131	000 260 1597	ZF 44	68	GEAR SET (26T.) (5 PCS.)	16 S 160
1297 232 023	T10131	000 260 1597	ZF 46	68	GEAR SET (26T.) (5 PCS.)	16 K 190
1297 232 023	T10131	000 260 1597	ZF 47	68	GEAR SET (26T.) (5 PCS.)	16 S 190
1297 232 023	T10131	000 260 1597	ZF 51	68	GEAR SET (26T.) (5 PCS.)	16 S 220
(1297 232 023/G)	T10134	000 260 1597/G	ZF 43	67	GEAR (26T.)	16 K 160
(1297 232 023/G)	T10134	000 260 1597/G	ZF 44	67	GEAR (26T.)	16 S 160
(1297 232 023/G)	T10134	000 260 1597/G	ZF 46	67	GEAR (26T.)	16 K 190
(1297 232 023/G)	T10134	000 260 1597/G	ZF 47	67	GEAR (26T.)	16 S 190
(1297 232 023/G)	T10134	000 260 1597/G	ZF 51	67	GEAR (26T.)	16 S 220
1297 232 024			ZF 41	68	GEAR SET (5 PCS.)	16 S 130
1297 232 024			ZF 43	68	GEAR SET (5 PCS.)	16 K 160
1297 232 024			ZF 44	68	GEAR SET (5 PCS.)	16 S 160
1297 232 024			ZF 46	68	GEAR SET (5 PCS.)	16 K 190
1297 232 024			ZF 47	68	GEAR SET (5 PCS.)	16 S 190
(1297 232 024/G)			ZF 41	67	GEAR	16 S 130
(1297 232 024/G)			ZF 43	67	GEAR	16 K 160
(1297 232 024/G)			ZF 44	67	GEAR	16 S 160
(1297 232 024/G)			ZF 46	67	GEAR	16 K 190
(1297 232 024/G)			ZF 47	67	GEAR	16 S 190
1297 232 026			ZF 41	60	CARRIER	16 S 130
1297 232 026			ZF 43	60	CARRIER	16 K 160
1297 232 026			ZF 44	60	CARRIER	16 S 160
1297 232 026			ZF 46	60	CARRIER	16 K 190
1297 232 026			ZF 47	60	CARRIER	16 S 190
1297 232 027			ZF 43	60	CARRIER	16 K 160
1297 232 027			ZF 44	60	CARRIER	16 S 160
1297 232 027			ZF 46	60	CARRIER	16 K 190
1297 232 027			ZF 47	60	CARRIER	16 S 190
1297 232 039			ZF 43	60	CARRIER	16 K 160
1297 232 039			ZF 44	60	CARRIER	16 S 160
1297 232 039			ZF 46	60	CARRIER	16 K 190
1297 232 039			ZF 47	60	CARRIER	16 S 190
1297 232 045			ZF 41	60	CARRIER	16 S 130
1297 232 045			ZF 43	60	CARRIER	16 K 160
1297 232 045			ZF 44	60	CARRIER	16 S 160
1297 232 045			ZF 46	60	CARRIER	16 K 190
1297 232 045			ZF 47	60	CARRIER	16 S 190
1297 233 056			ZF 47	78	SYNCHRONIZER CONE (63T.)	16 S 190
1297 233 056			ZF 51	78	SYNCHRONIZER CONE	16 S 220
1297 233 056			ZF 57	79	SYNCHRONIZER CONE	16 S 221
1297 302 011			ZF 37	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 112
1297 302 011			ZF 41	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 130
1297 302 011			ZF 44	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 012			ZF 37	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 112
1297 302 012			ZF 41	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 130
1297 302 013			ZF 37	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 112
1297 302 013			ZF 41	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 130
1297 302 013			ZF 43	32	MAIN DRIVE GEAR BEARING RETAINER	16 K 160
1297 302 013			ZF 44	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 013			ZF 47	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 190
1297 302 014			ZF 41	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 130
1297 302 015			ZF 41	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 130
1297 302 015			ZF 44	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 015			ZF 47	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 190
1297 302 017			ZF 43	32	MAIN DRIVE GEAR BEARING RETAINER	16 K 160
1297 302 018			ZF 40	31	MAIN DRIVE GEAR BEARING RETAINER	16 K 130
1297 302 018			ZF 43	32	MAIN DRIVE GEAR BEARING RETAINER	16 K 160
1297 302 019			ZF 40	31	MAIN DRIVE GEAR BEARING RETAINER	16 K 130
1297 302 019			ZF 43	32	MAIN DRIVE GEAR BEARING RETAINER	16 K 160
1297 302 025			ZF 41	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 130
1297 302 025			ZF 44	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 025			ZF 47	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 190
1297 302 029			ZF 41	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 130

PROGRESSIVE ORIGINAL REFERENCES



PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
1297 302 042			ZF 41	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 130
1297 302 042			ZF 44	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 042			ZF 47	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 190
1297 302 043			ZF 44	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 043			ZF 47	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 190
1297 302 053			ZF 40	31	MAIN DRIVE GEAR BEARING RETAINER	16 K 130
1297 302 053			ZF 43	32	MAIN DRIVE GEAR BEARING RETAINER	16 K 160
1297 302 053			ZF 46	33	MAIN DRIVE GEAR BEARING RETAINER	16 K 190
1297 302 056			ZF 41	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 130
1297 302 056			ZF 44	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 074	T15014	000 262 3210	ZF 44	1	CONSTANT GEAR (28T.)	16 S 160
1297 302 081			ZF 46	33	MAIN DRIVE GEAR BEARING RETAINER	16 K 190
1297 302 082			ZF 41	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 130
1297 302 082			ZF 44	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 082			ZF 47	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 190
1297 302 084			ZF 41	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 130
1297 302 084			ZF 44	38	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 099			ZF 41	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 130
1297 302 107			ZF 44	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 108			ZF 37	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 112
1297 302 108			ZF 41	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 130
1297 302 109			ZF 41	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 130
1297 302 109			ZF 43	33	MAIN DRIVE GEAR BEARING RETAINER	16 K 160
1297 302 109			ZF 44	38	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 112			ZF 44	38	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 117			ZF 44	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 126			ZF 43	32	MAIN DRIVE GEAR BEARING RETAINER	16 K 160
1297 302 127			ZF 41	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 130
1297 302 130			ZF 43	33	MAIN DRIVE GEAR BEARING RETAINER	16 K 160
1297 302 134			ZF 41	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 130
1297 302 158			ZF 43	33	MAIN DRIVE GEAR BEARING RETAINER	16 K 160
1297 302 167			ZF 44	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 169			ZF 41	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 130
1297 302 169			ZF 44	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 176	T09773	000 262 4510	ZF 43	1	CONSTANT GEAR (28T.)	16 K 160
1297 302 176	T09773	000 262 4510	ZF 44	1	CONSTANT GEAR (28T.)	16 S 160
1297 302 176	T09773	000 262 4510	ZF 46	1	CONSTANT GEAR (28T.)	16 K 190
1297 302 176	T09773	000 262 4510	ZF 47	1	CONSTANT GEAR (28T.)	16 S 190
1297 302 177	T11774	000 262 4610	ZF 43	1	CONSTANT GEAR (30T.)	16 K 160
1297 302 177	T11774	000 262 4610	ZF 44	1	CONSTANT GEAR (30T.)	16 S 160
1297 302 177	T11774	000 262 4610	ZF 46	1	CONSTANT GEAR (30T.)	16 K 190
1297 302 177	T11774	000 262 4610	ZF 47	1	CONSTANT GEAR (30T.)	16 S 190
1297 302 180			ZF 41	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 130
1297 302 184			ZF 44	38	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 185			ZF 43	33	MAIN DRIVE GEAR BEARING RETAINER	16 K 160
1297 302 185			ZF 46	34	MAIN DRIVE GEAR BEARING RETAINER	16 K 190
1297 302 235			ZF 44	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 238			ZF 40	31	MAIN DRIVE GEAR BEARING RETAINER	16 K 130
1297 302 238			ZF 43	32	MAIN DRIVE GEAR BEARING RETAINER	16 K 160
1297 302 239			ZF 41	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 130
1297 302 239			ZF 44	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 239			ZF 47	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 190
1297 302 241			ZF 44	1	CONSTANT GEAR (26T.)	16 S 160
1297 302 241			ZF 47	1	CONSTANT GEAR (26T.)	16 S 190
1297 302 250			ZF 43	1	CONSTANT GEAR (29T.)	16 K 160
1297 302 250			ZF 44	1	CONSTANT GEAR (29T.)	16 S 160
1297 302 250			ZF 46	1	CONSTANT GEAR (29T.)	16 K 190
1297 302 250			ZF 47	1	CONSTANT GEAR (29T.)	16 S 190
1297 302 268			ZF 41	36	MAIN DRIVE GEAR BEARING RETAINER	16 S 130
1297 302 268			ZF 44	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 268			ZF 47	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 190
1297 302 270			ZF 44	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 272			ZF 44	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 160
1297 302 272			ZF 47	37	MAIN DRIVE GEAR BEARING RETAINER	16 S 190
1297 302 289			ZF 43	32	MAIN DRIVE GEAR BEARING RETAINER	16 K 160
1297 303 047	T11167	000 263 3302	ZF 43	28	COUNTERSHAFT (17-20T.)	16 K 160
1297 303 048			ZF 43	28	COUNTERSHAFT (19-23T.)	16 K 160
1297 303 065	T15026	000 263 6510	ZF 43	26	COUNTERSHAFT FOURTH SPEED GEAR (31T.)	16 K 160
1297 303 065	T15026	000 263 6510	ZF 44	31	COUNTERSHAFT FOURTH SPEED GEAR (31T.)	16 S 160
1297 303 065	T15026	000 263 6510	ZF 46	27	COUNTERSHAFT FOURTH SPEED GEAR (31T.)	16 K 190
1297 303 065	T15026	000 263 6510	ZF 47	31	COUNTERSHAFT FOURTH SPEED GEAR (31T.)	16 S 190
1297 303 066	T15033	000 263 6610	ZF 43	25	COUNTERSHAFT CONSTANT GEAR (34T.)	16 K 160
1297 303 066	T15033	000 263 6610	ZF 44	30	COUNTERSHAFT CONSTANT GEAR (34T.)	16 S 160
1297 303 066	T15033	000 263 6610	ZF 46	26	COUNTERSHAFT CONSTANT GEAR (34T.)	16 K 190
1297 303 066	T15033	000 263 6610	ZF 47	30	COUNTERSHAFT CONSTANT GEAR (34T.)	16 S 190
1297 303 067	T09789	000 263 7410	ZF 44	32	COUNTERSHAFT THIRD SPEED GEAR (25T.)	16 S 160

I riferimenti originali sono riportati solo come indicazione di particolari originali corrispondenti.
 All manufactures' names, numbers, symbols and descriptions are used for reference purposes only, and it is not implied that any part listed is the product of these manufacturers.

PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
1297 303 067	T09789	000 263 7410	ZF 47	32	COUNTERSHAFT THIRD SPEED GEAR (25T.)	16 S 190
1297 303 070			ZF 43	28	COUNTERSHAFT (19-23T.)	16 K 160
1297 303 072	T15047	000 263 7010	ZF 43	26	COUNTERSHAFT FOURTH SPEED GEAR (34T.)	16 K 160
1297 303 072	T15047	000 263 7010	ZF 44	31	COUNTERSHAFT FOURTH SPEED GEAR (34T.)	16 S 160
1297 303 072	T15047	000 263 7010	ZF 46	27	COUNTERSHAFT FOURTH SPEED GEAR (34T.)	16 K 190
1297 303 072	T15047	000 263 7010	ZF 47	31	COUNTERSHAFT FOURTH SPEED GEAR (34T.)	16 S 190
1297 303 073			ZF 44	32	COUNTERSHAFT THIRD SPEED GEAR (28T.)	16 S 160
1297 303 073			ZF 47	32	COUNTERSHAFT THIRD SPEED GEAR (28T.)	16 S 190
1297 303 074	T15040	000 263 6910	ZF 43	25	COUNTERSHAFT CONSTANT GEAR (31T.)	16 K 160
1297 303 074	T15040	000 263 6910	ZF 44	30	COUNTERSHAFT CONSTANT GEAR (31T.)	16 S 160
1297 303 074	T15040	000 263 6910	ZF 46	26	COUNTERSHAFT CONSTANT GEAR (31T.)	16 K 190
1297 303 074	T15040	000 263 6910	ZF 47	30	COUNTERSHAFT CONSTANT GEAR (31T.)	16 S 190
1297 303 075			ZF 44	33	COUNTERSHAFT (19-23T.)	16 S 160
1297 303 075			ZF 47	33	COUNTERSHAFT (19-23T.)	16 S 190
1297 303 076			ZF 46	29	COUNTERSHAFT (17T.)	16 K 190
1297 303 077			ZF 43	27	COUNTERSHAFT THIRD SPEED GEAR (25T.)	16 K 160
1297 303 077			ZF 46	28	COUNTERSHAFT THIRD SPEED GEAR (25T.)	16 K 190
1297 303 080			ZF 46	29	COUNTERSHAFT (19T.)	16 K 190
1297 303 081			ZF 43	27	COUNTERSHAFT THIRD SPEED GEAR (28T.)	16 K 160
1297 303 081			ZF 46	28	COUNTERSHAFT THIRD SPEED GEAR (28T.)	16 K 190
1297 303 086			ZF 44	30	COUNTERSHAFT CONSTANT GEAR (35T.)	16 S 160
1297 303 086			ZF 47	30	COUNTERSHAFT CONSTANT GEAR (35T.)	16 S 190
1297 303 097			ZF 44	31	COUNTERSHAFT FOURTH SPEED GEAR (35T.)	16 S 160
1297 303 097			ZF 47	31	COUNTERSHAFT FOURTH SPEED GEAR (35T.)	16 S 190
1297 303 098			ZF 43	25	COUNTERSHAFT CONSTANT GEAR (32T.)	16 K 160
1297 303 098			ZF 44	30	COUNTERSHAFT CONSTANT GEAR (32T.)	16 S 160
1297 303 098			ZF 46	26	COUNTERSHAFT CONSTANT GEAR (32T.)	16 K 190
1297 303 098			ZF 47	30	COUNTERSHAFT CONSTANT GEAR (32T.)	16 S 190
1297 303 114			ZF 43	26	COUNTERSHAFT FOURTH SPEED GEAR (39T.)	16 K 160
1297 303 114			ZF 46	27	COUNTERSHAFT FOURTH SPEED GEAR (39T.)	16 K 190
1297 303 123			ZF 44	31	COUNTERSHAFT FOURTH SPEED GEAR (32T.)	16 S 160
1297 303 123			ZF 47	31	COUNTERSHAFT FOURTH SPEED GEAR (32T.)	16 S 190
1297 303 132			ZF 44	32	COUNTERSHAFT THIRD SPEED GEAR (26T.)	16 S 160
1297 303 132			ZF 47	32	COUNTERSHAFT THIRD SPEED GEAR (26T.)	16 S 190
1297 303 140			ZF 44	33	COUNTERSHAFT (17-20T.)	16 S 160
1297 303 140			ZF 47	33	COUNTERSHAFT (17-20T.)	16 S 190
1297 304 031	T08892	000 262 3935	ZF 37	15	SYNCHRONIZER HUB	16 S 112
1297 304 031	T08892	000 262 3935	ZF 37	22	SYNCHRONIZER HUB	16 S 112
1297 304 031	T08892	000 262 3935	ZF 41	15	SYNCHRONIZER HUB	16 S 130
1297 304 031	T08892	000 262 3935	ZF 41	22	SYNCHRONIZER HUB	16 S 130
1297 304 031	T08892	000 262 3935	ZF 44	15	SYNCHRONIZER HUB	16 S 160
1297 304 031	T08892	000 262 3935	ZF 47	15	SYNCHRONIZER HUB	16 S 190
1297 304 034	T09755	000 262 2350	ZF 43	22	REVERSE GEAR SLEEVE	16 K 160
1297 304 034	T09755	000 262 2350	ZF 44	27	REVERSE GEAR SLEEVE	16 S 160
1297 304 034	T09755	000 262 2350	ZF 46	23	REVERSE GEAR SLEEVE	16 K 190
1297 304 034	T09755	000 262 2350	ZF 47	27	REVERSE GEAR SLEEVE	16 S 190
1297 304 035	T09757	000 262 2450	ZF 44	24	FIRST SPEED GEAR SLEEVE	16 S 160
1297 304 035	T09757	000 262 2450	ZF 47	24	FIRST SPEED GEAR SLEEVE	16 S 190
1297 304 055	T09765	000 262 3050	ZF 43	19	FIRST SPEED GEAR SLEEVE	16 K 160
1297 304 055	T09765	000 262 3050	ZF 46	20	FIRST SPEED GEAR SLEEVE	16 K 190
1297 304 112	T09769	000 262 3912	ZF 43	16	SECOND SPEED GEAR (38T.)	16 K 160
1297 304 113			ZF 43	16	SECOND SPEED GEAR (37T.)	16 K 160
1297 304 115	T09775	000 262 4713	ZF 43	14	THIRD SPEED GEAR (34T.)	16 K 160
1297 304 116			ZF 43	14	THIRD SPEED GEAR (32T.)	16 K 160
1297 304 119	T09777	000 262 4923	ZF 43	18	FIRST AND SECOND SPEED SLIDING COLLAR	16 K 160
1297 304 119	T09777	000 262 4923	ZF 46	19	FIRST AND SECOND SPEED SLIDING COLLAR	16 K 190
1297 304 120	T09779	000 262 5023	ZF 43	13	THIRD AND FOURTH SPEED SLIDING COLLAR	16 K 160
1297 304 120	T09779	000 262 5023	ZF 46	14	THIRD AND FOURTH SPEED SLIDING COLLAR	16 K 190
1297 304 127	T09767	000 262 3214	ZF 43	11	FOURTH SPEED GEAR (30T.)	16 K 160
1297 304 128			ZF 43	11	FOURTH SPEED GEAR (28T.)	16 K 160
1297 304 148			ZF 43	23	REVERSE GEAR (38T.)	16 K 160
1297 304 148			ZF 44	28	REVERSE GEAR (38T.)	16 S 160
1297 304 148			ZF 46	24	REVERSE GEAR (38T.)	16 K 190
1297 304 148			ZF 47	28	REVERSE GEAR (38T.)	16 S 190
1297 304 149			ZF 43	23	REVERSE GEAR (39T.)	16 K 160
1297 304 149			ZF 44	28	REVERSE GEAR (39T.)	16 S 160
1297 304 149			ZF 46	24	REVERSE GEAR (39T.)	16 K 190
1297 304 149			ZF 47	28	REVERSE GEAR (39T.)	16 S 190
1297 304 150			ZF 43	20	FIRST SPEED GEAR (47T.)	16 K 160
1297 304 151			ZF 43	20	FIRST SPEED GEAR (44T.)	16 K 160
1297 304 154			ZF 43	21	FIRST SPEED AND REVERSE GEAR CONE	16 K 160
1297 304 154			ZF 44	26	FIRST SPEED AND REVERSE GEAR CONE	16 S 160
1297 304 154			ZF 46	22	FIRST SPEED AND REVERSE GEAR CONE	16 K 190
1297 304 154			ZF 47	26	FIRST SPEED AND REVERSE GEAR CONE	16 S 190
1297 304 179			ZF 43	15	MAINSHAFT	16 K 160
1297 304 179			ZF 46	16	MAINSHAFT	16 K 190

PROGRESSIVE ORIGINAL REFERENCES



PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
1297 304 181			ZF 44	18	MAINSHAFT	16 S 160
1297 304 181			ZF 47	18	MAINSHAFT	16 S 190
1297 304 187			ZF 43	24	PLANETARY REDUCTION SUN GEAR (27T.)	16 K 160
1297 304 187			ZF 44	29	PLANETARY REDUCTION SUN GEAR (27T.)	16 S 160
1297 304 187			ZF 46	25	PLANETARY REDUCTION SUN GEAR (27T.)	16 K 190
1297 304 187			ZF 47	29	PLANETARY REDUCTION SUN GEAR (27T.)	16 S 190
1297 304 188			ZF 43	12	THIRD AND FOURTH SPEED CLUTCH GEAR	16 K 160
1297 304 188			ZF 46	13	THIRD AND FOURTH SPEED CLUTCH GEAR	16 K 190
1297 304 193			ZF 44	18	MAINSHAFT	16 S 160
1297 304 193			ZF 47	18	MAINSHAFT	16 S 190
1297 304 195	T08895	000 262 4435	ZF 37	22	SYNCHRONIZER HUB	16 S 112
1297 304 195	T08895	000 262 4435	ZF 41	22	SYNCHRONIZER HUB	16 S 130
1297 304 195	T08895	000 262 4435	ZF 44	22	SYNCHRONIZER HUB	16 S 160
1297 304 195	T08895	000 262 4435	ZF 47	22	SYNCHRONIZER HUB	16 S 190
1297 304 196	T09054	000 262 2140	ZF 37	20	SYNCHRONIZER CONE (63T.)	16 S 112
1297 304 196	T09054	000 262 2140	ZF 41	20	SYNCHRONIZER CONE (63T.)	16 S 130
1297 304 196	T09054	000 262 2140	ZF 44	20	SYNCHRONIZER CONE (63T.)	16 S 160
1297 304 196	T09054	000 262 2140	ZF 47	20	SYNCHRONIZER CONE (63T.)	16 S 190
1297 304 258			ZF 43	11	FOURTH SPEED GEAR (29T.)	16 K 160
1297 304 260	T15019	000 262 4414	ZF 44	12	FOURTH SPEED GEAR (30T.)	16 S 160
1297 304 260	T15019	000 262 4414	ZF 47	12	FOURTH SPEED GEAR (30T.)	16 S 190
1297 304 261			ZF 44	17	THIRD SPEED GEAR (34T.)	16 S 160
1297 304 261			ZF 47	17	THIRD SPEED GEAR (34T.)	16 S 190
1297 304 264			ZF 43	15	MAINSHAFT	16 K 160
1297 304 264			ZF 46	16	MAINSHAFT	16 K 190
1297 304 265			ZF 43	24	PLANETARY REDUCTION SUN GEAR (24T.)	16 K 160
1297 304 265			ZF 46	25	PLANETARY REDUCTION SUN GEAR (24T.)	16 K 190
1297 304 266			ZF 44	17	THIRD SPEED GEAR (32T.)	16 S 160
1297 304 266			ZF 47	17	THIRD SPEED GEAR (32T.)	16 S 190
1297 304 267	T15016	000 262 4214	ZF 44	12	FOURTH SPEED GEAR (28T.)	16 S 160
1297 304 267	T15016	000 262 4214	ZF 47	12	FOURTH SPEED GEAR (28T.)	16 S 190
1297 304 269			ZF 44	19	SECOND SPEED GEAR (37T.)	16 S 160
1297 304 269			ZF 47	19	SECOND SPEED GEAR (37T.)	16 S 190
1297 304 270			ZF 44	25	FIRST SPEED GEAR (44T.)	16 S 160
1297 304 270			ZF 47	25	FIRST SPEED GEAR (44T.)	16 S 190
1297 304 271			ZF 46	17	SECOND SPEED GEAR (38T.)	16 K 190
1297 304 272			ZF 46	21	FIRST SPEED GEAR (47T.)	16 K 190
1297 304 273			ZF 46	15	THIRD SPEED GEAR (34T.)	16 K 190
1297 304 274			ZF 46	12	FOURTH SPEED GEAR (30T.)	16 K 190
1297 304 277			ZF 46	21	FIRST SPEED GEAR (44T.)	16 K 190
1297 304 278			ZF 46	17	SECOND SPEED GEAR (37T.)	16 K 190
1297 304 279			ZF 46	15	THIRD SPEED GEAR (32T.)	16 K 190
1297 304 308			ZF 46	12	FOURTH SPEED GEAR (28T.)	16 K 190
1297 304 318			ZF 44	12	FOURTH SPEED GEAR (26T.)	16 S 160
1297 304 318			ZF 47	12	FOURTH SPEED GEAR (26T.)	16 S 190
1297 304 380			ZF 46	12	FOURTH SPEED GEAR (29T.)	16 K 190
1297 304 401			ZF 50	27	SYNCHRONIZER BLOCKING RING	16 S 150
1297 304 401			ZF 51	27	SYNCHRONIZER BLOCKING RING	16 S 220
1297 304 401			ZF 55	26	SYNCHRONIZER BLOCKING RING	16 S 151
1297 304 401			ZF 56	26	SYNCHRONIZER BLOCKING RING	16 S 181
1297 304 401			ZF 57	26	SYNCHRONIZER BLOCKING RING	16 S 221
1297 304 401			ZF 58	19	SYNCHRONIZER BLOCKING RING	16 S 251
1297 304 402	T11724	000 262 3834	ZF 50	3	SYNCHRONIZER BLOCKING RING	16 S 150
1297 304 402	T11724	000 262 3834	ZF 50	13	SYNCHRONIZER BLOCKING RING	16 S 150
1297 304 402	T11724	000 262 3834	ZF 51	3	SYNCHRONIZER BLOCKING RING	16 S 220
1297 304 402	T11724	000 262 3834	ZF 51	13	SYNCHRONIZER BLOCKING RING	16 S 220
1297 304 402	T11724	000 262 3834	ZF 55	3	SYNCHRONIZER BLOCKING RING	16 S 151
1297 304 402	T11724	000 262 3834	ZF 55	11	SYNCHRONIZER BLOCKING RING	16 S 151
1297 304 402	T11724	000 262 3834	ZF 56	3	SYNCHRONIZER BLOCKING RING	16 S 181
1297 304 402	T11724	000 262 3834	ZF 56	11	SYNCHRONIZER BLOCKING RING	16 S 181
1297 304 402	T11724	000 262 3834	ZF 57	3	SYNCHRONIZER BLOCKING RING	16 S 221
1297 304 402	T11724	000 262 3834	ZF 57	11	SYNCHRONIZER BLOCKING RING	16 S 221
1297 304 402	T11724	000 262 3834	ZF 58	3	SYNCHRONIZER BLOCKING RING	16 S 251
1297 304 402	T11724	000 262 3834	ZF 58	11	SYNCHRONIZER BLOCKING RING	16 S 251
1297 304 413			ZF 44	12	FOURTH SPEED GEAR (29T.)	16 S 160
1297 304 413			ZF 47	12	FOURTH SPEED GEAR (29T.)	16 S 190
1297 304 414			ZF 44	17	THIRD SPEED GEAR (34T.)	16 S 160
1297 304 414			ZF 47	17	THIRD SPEED GEAR (34T.)	16 S 190
1297 304 436	T15096	000 264 0839	ZF 50	8	SYNCHRONIZER PRESSURE PLUNGER	16 S 150
1297 304 436	T15096	000 264 0839	ZF 51	8	SYNCHRONIZER PRESSURE PLUNGER	16 S 220
1297 304 436	T15096	000 264 0839	ZF 55	6	SYNCHRONIZER PRESSURE PLUNGER	16 S 151
1297 304 436	T15096	000 264 0839	ZF 56	6	SYNCHRONIZER PRESSURE PLUNGER	16 S 181
1297 304 436	T15096	000 264 0839	ZF 57	6	SYNCHRONIZER PRESSURE PLUNGER	16 S 221
1297 304 436	T15096	000 264 0839	ZF 58	6	SYNCHRONIZER PRESSURE PLUNGER	16 S 251
1297 304 439			ZF 44	29	PLANETARY REDUCTION SUN GEAR (24T.)	16 S 160
1297 304 439			ZF 47	29	PLANETARY REDUCTION SUN GEAR (24T.)	16 S 190

I riferimenti originali sono riportati solo come indicazione di particolari originali corrispondenti.
 All manufactures' names, numbers, symbols and descriptions are used for reference purposes only, and it is not implied that any part listed is the product of these manufacturers.



PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
1297 304 441			ZF 44	25	FIRST SPEED GEAR (47T.)	16 S 160
1297 304 441			ZF 47	25	FIRST SPEED GEAR (47T.)	16 S 190
1297 304 442			ZF 44	19	SECOND SPEED GEAR (38T.)	16 S 160
1297 304 442			ZF 47	19	SECOND SPEED GEAR (38T.)	16 S 190
1297 304 484	T15078	000 262 7034	ZF 50	3	SYNCHRONIZER BLOCKING RING	16 S 150
1297 304 484	T15078	000 262 7034	ZF 50	13	SYNCHRONIZER BLOCKING RING	16 S 150
1297 304 484	T15078	000 262 7034	ZF 51	3	SYNCHRONIZER BLOCKING RING	16 S 220
1297 304 484	T15078	000 262 7034	ZF 51	13	SYNCHRONIZER BLOCKING RING	16 S 220
1297 304 484	T15078	000 262 7034	ZF 55	3	SYNCHRONIZER BLOCKING RING	16 S 151
1297 304 484	T15078	000 262 7034	ZF 55	11	SYNCHRONIZER BLOCKING RING	16 S 151
1297 304 484	T15078	000 262 7034	ZF 56	3	SYNCHRONIZER BLOCKING RING	16 S 181
1297 304 484	T15078	000 262 7034	ZF 56	11	SYNCHRONIZER BLOCKING RING	16 S 181
1297 304 484	T15078	000 262 7034	ZF 57	3	SYNCHRONIZER BLOCKING RING	16 S 221
1297 304 484	T15078	000 262 7034	ZF 57	11	SYNCHRONIZER BLOCKING RING	16 S 221
1297 304 484	T15078	000 262 7034	ZF 58	3	SYNCHRONIZER BLOCKING RING	16 S 251
1297 304 484	T15078	000 262 7034	ZF 58	11	SYNCHRONIZER BLOCKING RING	16 S 251
1297 304 485			ZF 50	27	SYNCHRONIZER BLOCKING RING	16 S 150
1297 304 485			ZF 51	27	SYNCHRONIZER BLOCKING RING	16 S 220
1297 304 485			ZF 55	26	SYNCHRONIZER BLOCKING RING	16 S 151
1297 304 485			ZF 56	26	SYNCHRONIZER BLOCKING RING	16 S 181
1297 304 485			ZF 57	26	SYNCHRONIZER BLOCKING RING	16 S 221
1297 304 485			ZF 58	19	SYNCHRONIZER BLOCKING RING	16 S 251
1297 305 003			ZF 40	29	REVERSE IDLER GEAR (21T.)	16 K 130
1297 305 003			ZF 41	34	REVERSE IDLER GEAR (21T.)	16 S 130
1297 305 011			ZF 51	41	REVERSE IDLER GEAR (24T.)	16 S 220
1297 305 012			ZF 51	41	REVERSE IDLER GEAR (21T.)	16 S 220
1297 306 120			ZF 50	90	SLIDING BLOCK	16 S 150
1297 306 120			ZF 51	90	SLIDING BLOCK	16 S 220
1297 306 120			ZF 55	90	SLIDING BLOCK	16 S 151
1297 306 120			ZF 57	90	SLIDING BLOCK	16 S 221
1297 306 120			ZF 58	90	SLIDING BLOCK	16 S 251
1297 332 017			ZF 43	70	RING GEAR CARRIER (83T.)	16 K 160
1297 332 017			ZF 44	70	RING GEAR CARRIER (83T.)	16 S 160
1297 332 017			ZF 46	70	RING GEAR CARRIER (83T.)	16 K 190
1297 332 017			ZF 47	70	RING GEAR CARRIER (83T.)	16 S 190
1297 332 035			ZF 41	70	RING GEAR CARRIER (86T.)	16 S 130
1297 332 035			ZF 43	70	RING GEAR CARRIER (86T.)	16 K 160
1297 332 035			ZF 44	70	RING GEAR CARRIER (86T.)	16 S 160
1297 332 035			ZF 46	70	RING GEAR CARRIER (86T.)	16 K 190
1297 332 035			ZF 47	70	RING GEAR CARRIER (86T.)	16 S 190
1297 332 080			ZF 43	69	RING GEAR (83T.)	16 K 160
1297 332 080			ZF 44	69	RING GEAR (83T.)	16 S 160
1297 332 080			ZF 46	69	RING GEAR (83T.)	16 K 190
1297 332 080			ZF 47	69	RING GEAR (83T.)	16 S 190
1297 332 080			ZF 51	69	RING GEAR (83T.)	16 S 220
1297 332 108			ZF 51	70	RING GEAR CARRIER (83T.)	16 S 220
1297 332 109			ZF 41	61	GEAR SHAFT	16 S 130
1297 332 109			ZF 43	61	GEAR SHAFT	16 K 160
1297 332 109			ZF 44	61	GEAR SHAFT	16 S 160
1297 332 109			ZF 46	61	GEAR SHAFT	16 K 190
1297 332 109			ZF 47	61	GEAR SHAFT	16 S 190
1297 332 109			ZF 51	61	GEAR SHAFT	16 S 220
1297 332 120			ZF 47	70	RING GEAR CARRIER (86T.)	16 S 190
1297 332 120			ZF 51	70	RING GEAR CARRIER (86T.)	16 S 220
1297 332 120			ZF 57	71	RING GEAR CARRIER (86T.)	16 S 221
1297 333 110			ZF 47	80	CARRIER COUPLING FLANGE	16 S 190
1297 333 110			ZF 51	80	CARRIER COUPLING FLANGE	16 S 220
1297 333 110			ZF 55	84	CARRIER COUPLING FLANGE	16 S 151
1297 333 110			ZF 56	81	CARRIER COUPLING FLANGE	16 S 181
1297 333 110			ZF 57	85	CARRIER COUPLING FLANGE	16 S 221
1297 333 110			ZF 58	81	CARRIER COUPLING FLANGE	16 S 251
1297 333 115			ZF 47	73	SYNCHRONIZER HUB	16 S 190
1297 333 115			ZF 51	73	SYNCHRONIZER HUB	16 S 220
1297 333 115			ZF 57	74	SYNCHRONIZER HUB	16 S 221
1297 333 117			ZF 41	79	SYNCHRONIZER CONE	16 S 130
1297 333 118			ZF 41	79	SYNCHRONIZER CONE	16 S 130
1297 333 118			ZF 47	79	SYNCHRONIZER CONE	16 S 190
1297 333 118			ZF 50	79	SYNCHRONIZER CONE	16 S 150
1297 338 003			ZF 47	80	CARRIER COUPLING FLANGE	16 S 190
1297 338 008			ZF 46	79	CARRIER COUPLING FLANGE	16 K 190
1297 338 009			ZF 44	79	CARRIER COUPLING FLANGE	16 S 160
1297 338 009			ZF 46	79	CARRIER COUPLING FLANGE	16 K 190
1297 338 010			ZF 41	80	CARRIER COUPLING FLANGE	16 S 130
1297 338 010			ZF 43	79	CARRIER COUPLING FLANGE	16 K 160
1297 338 010			ZF 44	79	CARRIER COUPLING FLANGE	16 S 160
1297 338 010			ZF 46	79	CARRIER COUPLING FLANGE	16 K 190

PROGRESSIVE ORIGINAL REFERENCES



PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
1297 338 010			ZF 47	80	CARRIER COUPLING FLANGE	16 S 190
1297 338 038	T14812	000 264 4145	ZF 43	79	CARRIER COUPLING FLANGE (38 SPLINES)	16 K 160
1297 338 038	T14812	000 264 4145	ZF 44	79	CARRIER COUPLING FLANGE (38 SPLINES)	16 S 160
1297 338 038	T14812	000 264 4145	ZF 46	79	CARRIER COUPLING FLANGE (38 SPLINES)	16 K 190
1297 338 038	T14812	000 264 4145	ZF 47	80	CARRIER COUPLING FLANGE	16 S 190
1297 338 041			ZF 41	80	CARRIER COUPLING FLANGE	16 S 130
1297 338 041			ZF 43	79	CARRIER COUPLING FLANGE	16 K 160
1297 338 041			ZF 44	79	CARRIER COUPLING FLANGE	16 S 160
1297 338 041			ZF 47	80	CARRIER COUPLING FLANGE	16 S 190
1297 338 051			ZF 43	79	CARRIER COUPLING FLANGE	16 K 160
1304 304 686	T15151	000 262 9934	ZF 37	3	SYNCHRONIZER BLOCKING RING	16 S 112
1304 304 686	T15151	000 262 9934	ZF 37	14	SYNCHRONIZER BLOCKING RING	16 S 112
1304 304 686	T15151	000 262 9934	ZF 40	3	SYNCHRONIZER BLOCKING RING	16 K 130
1304 304 686	T15151	000 262 9934	ZF 41	3	SYNCHRONIZER BLOCKING RING	16 S 130
1304 304 686	T15151	000 262 9934	ZF 41	14	SYNCHRONIZER BLOCKING RING	16 S 130
1304 304 686	T15151	000 262 9934	ZF 43	3	SYNCHRONIZER BLOCKING RING	16 K 160
1304 304 686	T15151	000 262 9934	ZF 44	3	SYNCHRONIZER BLOCKING RING	16 S 160
1304 304 686	T15151	000 262 9934	ZF 44	14	SYNCHRONIZER BLOCKING RING	16 S 160
1304 304 686	T15151	000 262 9934	ZF 46	3	SYNCHRONIZER BLOCKING RING	16 K 190
1304 304 686	T15151	000 262 9934	ZF 47	3	SYNCHRONIZER BLOCKING RING	16 S 190
1304 304 686	T15151	000 262 9934	ZF 47	14	SYNCHRONIZER BLOCKING RING	16 S 190
1310 304 174	T11727	000 262 6623	ZF 57	7	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 221
1310 304 175	T14989	001 262 1123	ZF 50	25	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 150
1310 304 175	T14989	001 262 1123	ZF 51	25	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 220
1310 304 175	T14989	001 262 1123	ZF 55	24	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 151
1310 304 175	T14989	001 262 1123	ZF 56	24	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 181
1310 304 175	T14989	001 262 1123	ZF 57	24	SYNCHRONIZER SLIDING COLLAR (63T.)	16 S 221
1310 304 202	T14983	000 262 1823	ZF 50	9	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 150
1310 304 202	T14983	000 262 1823	ZF 51	9	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 220
1310 304 202	T14983	000 262 1823	ZF 55	7	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 151
1310 304 202	T14983	000 262 1823	ZF 56	7	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 181
1310 304 202	T14983	000 262 1823	ZF 57	7	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 221
1310 304 202	T14983	000 262 1823	ZF 58	7	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 251
1310 304 202	T14983	000 262 1823	ZF 50	15	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 150
1310 304 202	T14983	000 262 1823	ZF 51	15	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 220
1310 304 202	T14983	000 262 1823	ZF 55	13	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 151
1310 304 202	T14983	000 262 1823	ZF 56	13	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 181
1310 304 202	T14983	000 262 1823	ZF 57	13	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 221
1310 304 202	T14983	000 262 1823	ZF 58	13	SYNCHRONIZER SLIDING COLLAR (57T.)	16 S 251
1312 202 035			ZF 51	4	MAIN DRIVE GEAR	16 S 220
1312 202 036			ZF 51	4	MAIN DRIVE GEAR	16 S 220
1312 202 037			ZF 51	4	MAIN DRIVE GEAR	16 S 220
1312 202 038			ZF 51	4	MAIN DRIVE GEAR	16 S 220
1312 202 039			ZF 51	4	MAIN DRIVE GEAR	16 S 220
1312 202 041			ZF 51	5	MAIN DRIVE GEAR	16 S 220
1312 202 054			ZF 50	43	MAIN DRIVE GEAR BEARING RETAINER	16 S 150
1312 221 003			ZF 51	4	MAIN DRIVE GEAR	16 S 220
1312 232 011			ZF 57	69	GEAR SET (5 pcs.)	16 S 221
(1312 232 011/G)			ZF 57	68	GEAR	16 S 221
1312 232 013			ZF 47	60	CARRIER	16 S 190
1312 232 014			ZF 47	68	GEAR SET (5 pcs.)	16 S 190
1312 232 014			ZF 51	68	GEAR SET (5 pcs.)	16 S 220
1312 232 014			ZF 57	69	GEAR SET (5 pcs.)	16 S 221
(1312 232 014/G)			ZF 47	67	GEAR	16 S 190
(1312 232 014/G)			ZF 51	67	GEAR	16 S 220
(1312 232 014/G)			ZF 57	68	GEAR	16 S 221
1312 232 015			ZF 51	60	CARRIER	16 S 220
1312 232 015			ZF 57	60	CARRIER	16 S 221
1312 232 016			ZF 51	60	CARRIER	16 S 220
1312 232 028			ZF 51	60	CARRIER	16 S 220
1312 302 036			ZF 50	43	MAIN DRIVE GEAR BEARING RETAINER	16 S 150
1312 302 036			ZF 51	43	MAIN DRIVE GEAR BEARING RETAINER	16 S 220
1312 302 044			ZF 51	43	MAIN DRIVE GEAR BEARING RETAINER	16 S 220
1312 302 047			ZF 50	43	MAIN DRIVE GEAR BEARING RETAINER	16 S 150
1312 302 047			ZF 51	43	MAIN DRIVE GEAR BEARING RETAINER	16 S 220
1312 302 052			ZF 50	43	MAIN DRIVE GEAR BEARING RETAINER	16 S 150
1312 302 061			ZF 51	44	MAIN DRIVE GEAR BEARING RETAINER	16 S 220
1312 302 064			ZF 51	44	MAIN DRIVE GEAR BEARING RETAINER	16 S 220
1312 302 073			ZF 51	1	CONSTANT GEAR (34T.)	16 S 220
1312 302 074			ZF 51	1	CONSTANT GEAR (30T.)	16 S 220
1312 302 077			ZF 51	1	CONSTANT GEAR (28T.)	16 S 220
1312 302 081			ZF 50	43	MAIN DRIVE GEAR BEARING RETAINER	16 S 150
1312 302 096			ZF 50	43	MAIN DRIVE GEAR BEARING RETAINER	16 S 150
1312 302 096			ZF 51	43	MAIN DRIVE GEAR BEARING RETAINER	16 S 220
1312 303 003			ZF 51	35	COUNTERSHAFT CONSTANT GEAR (34T.)	16 S 220
1312 303 005			ZF 51	35	COUNTERSHAFT CONSTANT GEAR (39T.)	16 S 220

I riferimenti originali sono riportati solo come indicazione di particolari originali corrispondenti.
 All manufactures' names, numbers, symbols and descriptions are used for reference purposes only, and it is not implied that any part listed is the product of these manufacturers.



PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
1312 303 006			ZF 51	35	COUNTERSHAFT CONSTANT GEAR (37T.)	16 S 220
1312 303 008			ZF 51	38	COUNTERSHAFT (17-20T.)	16 S 220
1312 303 009			ZF 51	38	COUNTERSHAFT (19-23T.)	16 S 220
1312 303 014			ZF 51	36	COUNTERSHAFT FOURTH SPEED GEAR (31T.)	16 S 220
1312 303 016			ZF 51	36	COUNTERSHAFT FOURTH SPEED GEAR (37T.)	16 S 220
1312 303 017			ZF 51	36	COUNTERSHAFT FOURTH SPEED GEAR (39T.)	16 S 220
1312 303 020			ZF 51	37	COUNTERSHAFT THIRD SPEED GEAR (28T.)	16 S 220
1312 303 021			ZF 51	37	COUNTERSHAFT THIRD SPEED GEAR (26T.)	16 S 220
1312 303 036			ZF 51	37	COUNTERSHAFT THIRD SPEED GEAR (28T.)	16 S 220
1312 303 037			ZF 51	38	COUNTERSHAFT (20-24T.)	16 S 220
1312 303 043			ZF 51	39	COUNTERSHAFT (19-23T.)	16 S 220
1312 303 055			ZF 51	38	COUNTERSHAFT	16 S 220
1312 304 008			ZF 51	30	FIRST SPEED GEAR SLEEVE	16 S 220
1312 304 011			ZF 51	33	REVERSE SPEED GEAR SLEEVE	16 S 220
1312 304 027	T11729	000 262 5535	ZF 50	2	SYNCHRONIZER CONE (57T.)	16 S 150
1312 304 027	T11729	000 262 5535	ZF 50	12	SYNCHRONIZER CONE (57T.)	16 S 150
1312 304 027	T11729	000 262 5535	ZF 51	2	SYNCHRONIZER CONE (57T.)	16 S 220
1312 304 027	T11729	000 262 5535	ZF 51	12	SYNCHRONIZER CONE (57T.)	16 S 220
1312 304 027	T11729	000 262 5535	ZF 55	2	SYNCHRONIZER CONE (57T.)	16 S 151
1312 304 027	T11729	000 262 5535	ZF 55	10	SYNCHRONIZER CONE (57T.)	16 S 151
1312 304 027	T11729	000 262 5535	ZF 56	2	SYNCHRONIZER CONE (57T.)	16 S 181
1312 304 027	T11729	000 262 5535	ZF 56	10	SYNCHRONIZER CONE (57T.)	16 S 181
1312 304 027	T11729	000 262 5535	ZF 57	2	SYNCHRONIZER CONE (57T.)	16 S 221
1312 304 027	T11729	000 262 5535	ZF 57	10	SYNCHRONIZER CONE (57T.)	16 S 221
1312 304 027	T11729	000 262 5535	ZF 58	2	SYNCHRONIZER CONE (57T.)	16 S 251
1312 304 027	T11729	000 262 5535	ZF 58	10	SYNCHRONIZER CONE (57T.)	16 S 251
1312 304 029			ZF 51	11	FOURTH SPEED GEAR (30T.)	16 S 220
1312 304 031			ZF 51	11	FOURTH SPEED GEAR (34T.)	16 S 220
1312 304 032			ZF 51	11	FOURTH SPEED GEAR (30T.)	16 S 220
1312 304 037			ZF 51	32	FIRST SPEED AND REVERSE GEAR CONE	16 S 220
1312 304 052			ZF 50	14	SYNCHRONIZER HUB	16 S 150
1312 304 052			ZF 51	14	SYNCHRONIZER HUB	16 S 220
1312 304 052			ZF 55	12	SYNCHRONIZER HUB	16 S 151
1312 304 052			ZF 56	12	SYNCHRONIZER HUB	16 S 181
1312 304 052			ZF 57	12	SYNCHRONIZER HUB	16 S 221
1312 304 052			ZF 58	12	SYNCHRONIZER HUB	16 S 251
1312 304 056	T15103		ZF 50	10	SYNCHRONIZER CONE (57T.)	16 S 150
1312 304 056	T15103		ZF 51	10	SYNCHRONIZER CONE (57T.)	16 S 220
1312 304 056	T15103		ZF 55	8	SYNCHRONIZER CONE (57T.)	16 S 151
1312 304 056	T15103		ZF 56	8	SYNCHRONIZER CONE (57T.)	16 S 181
1312 304 056	T15103		ZF 57	8	SYNCHRONIZER CONE (57T.)	16 S 221
1312 304 056	T15103		ZF 58	8	SYNCHRONIZER CONE (57T.)	16 S 251
1312 304 075			ZF 51	16	THIRD SPEED GEAR (25T.)	16 S 220
1312 304 077			ZF 51	31	FIRST SPEED GEAR (34T.)	16 S 220
1312 304 078			ZF 51	34	REVERSE GEAR (39T.)	16 S 220
1312 304 083			ZF 51	32	FIRST SPEED AND REVERSE GEAR CONE	16 S 220
1312 304 084			ZF 51	30	FIRST SPEED GEAR SLEEVE	16 S 220
1312 304 084			ZF 56	29	FIRST SPEED GEAR SLEEVE	16 S 181
1312 304 084			ZF 57	29	T/M FIRST SPEED GEAR SLEEVE	16 S 221
1312 304 084			ZF 58	22	FIRST SPEED GEAR SLEEVE	16 S 251
1312 304 085			ZF 51	31	FIRST SPEED GEAR (47T.)	16 S 220
1312 304 086			ZF 51	31	FIRST SPEED GEAR (44T.)	16 S 220
1312 304 087			ZF 51	34	REVERSE GEAR (38T.)	16 S 220
1312 304 088			ZF 51	34	REVERSE GEAR (39T.)	16 S 220
1312 304 092			ZF 51	19	SYNCHRONIZER CLUTCH GEAR	16 S 220
1312 304 097			ZF 55	16	MAINSHAFT TUBE	16 S 151
1312 304 097			ZF 56	16	MAINSHAFT TUBE	16 S 181
1312 304 097			ZF 57	16	MAINSHAFT TUBE	16 S 221
1312 304 106	T15090	000 263 2120	ZF 50	19	SYNCHRONIZER CLUTCH GEAR (63T.)	16 S 150
1312 304 106	T15090	000 263 2120	ZF 51	19	SYNCHRONIZER CLUTCH GEAR (63T.)	16 S 220
1312 304 106	T15090	000 263 2120	ZF 55	18	SYNCHRONIZER CLUTCH GEAR (63T.)	16 S 151
1312 304 106	T15090	000 263 2120	ZF 56	18	SYNCHRONIZER CLUTCH GEAR (63T.)	16 S 181
1312 304 106	T15090	000 263 2120	ZF 57	18	SYNCHRONIZER CLUTCH GEAR (63T.)	16 S 221
1312 304 124			ZF 56	31	FIRST SPEED AND REVERSE GEAR CONE	16 S 181
1312 304 124			ZF 57	31	FIRST SPEED AND REVERSE GEAR CONE	16 S 221
1312 304 124			ZF 58	24	FIRST SPEED AND REVERSE GEAR CONE	16 S 251
1312 304 134			ZF 51	17	MAINSHAFT	16 S 220
1312 304 136			ZF 51	16	THIRD SPEED GEAR (34T.)	16 S 220
1312 304 137			ZF 51	16	THIRD SPEED GEAR (32T.)	16 S 220
1312 304 139			ZF 51	18	SECOND SPEED GEAR (38T.)	16 S 220
1312 304 141			ZF 51	18	SECOND SPEED GEAR (37T.)	16 S 220
1312 304 142			ZF 51	18	SECOND SPEED GEAR	16 S 220
1312 304 150			ZF 55	16	MAINSHAFT TUBE	16 S 151
1312 304 150			ZF 56	16	MAINSHAFT TUBE	16 S 181
1312 304 150			ZF 57	16	MAINSHAFT TUBE	16 S 221
1312 304 158			ZF 50	24	SYNCHRONIZER HUB	16 S 150

PROGRESSIVE ORIGINAL REFERENCES



PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
1312 304 158			ZF 51	24	SYNCHRONIZER HUB	16 S 220
1312 304 158			ZF 55	23	SYNCHRONIZER HUB	16 S 151
1312 304 158			ZF 56	23	SYNCHRONIZER HUB	16 S 181
1312 304 158			ZF 57	23	SYNCHRONIZER HUB	16 S 221
1312 304 159			ZF 50	23	SYNCHRONIZER SHIFTING PLATE	16 S 150
1312 304 159			ZF 51	23	SYNCHRONIZER SHIFTING PLATE	16 S 220
1312 304 159			ZF 55	22	SYNCHRONIZER SHIFTING PLATE	16 S 151
1312 304 159			ZF 56	22	SYNCHRONIZER SHIFTING PLATE	16 S 181
1312 304 159			ZF 57	22	SYNCHRONIZER SHIFTING PLATE	16 S 221
1312 304 161			ZF 51	17	MAINSHAFT	16 S 220
1312 304 185			ZF 51	32	FIRST SPEED AND REVERSE GEAR CONE	16 S 220
1312 304 187			ZF 51	34	REVERSE GEAR (39T.)	16 S 220
1312 305 003			ZF 51	41	REVERSE IDLER GEAR (21T.)	16 S 220
1312 332 026			ZF 47	61	GEAR SHAFT	16 S 190
1312 332 026			ZF 51	61	GEAR SHAFT	16 S 220
1312 332 026			ZF 57	61	GEAR SHAFT	16 S 221
1312 333 014			ZF 51	79	SYNCHRONIZER CONE	16 S 220
1312 333 018			ZF 57	85	CARRIER COUPLING FLANGE	16 S 221
1313 202 013	T11730		ZF 50	4	MAIN DRIVE GEAR (57T.)	16 S 150
1313 202 014			ZF 50	4	MAIN DRIVE GEAR	16 S 150
1313 202 015			ZF 50	4	MAIN DRIVE GEAR	16 S 150
1313 202 016			ZF 50	4	MAIN DRIVE GEAR	16 S 150
1313 202 017			ZF 50	4	MAIN DRIVE GEAR	16 S 150
1313 202 018			ZF 50	4	MAIN DRIVE GEAR	16 S 150
1313 202 019			ZF 50	5	MAIN DRIVE GEAR	16 S 150
1313 202 023			ZF 50	4	MAIN DRIVE GEAR	16 S 150
1313 221 004			ZF 50	4	MAIN DRIVE GEAR	16 S 150
1313 221 006			ZF 50	4	MAIN DRIVE GEAR	16 S 150
1313 232 003			ZF 50	68	GEAR SET (5 pcs.)	16 S 150
1313 232 003			ZF 55	68	GEAR SET (5 pcs.)	16 S 151
(1313 232 003/G)			ZF 50	67	GEAR	16 S 150
(1313 232 003/G)			ZF 55	67	GEAR	16 S 151
1313 233 001	T14809	000 263 2020	ZF 41	78	SYNCHRONIZER CONE (63T.)	16 S 130
1313 233 001	T14809	000 263 2020	ZF 43	78	SYNCHRONIZER CONE (63T.)	16 K 160
1313 233 001	T14809	000 263 2020	ZF 44	78	SYNCHRONIZER CONE (63T.)	16 S 160
1313 233 001	T14809	000 263 2020	ZF 46	78	SYNCHRONIZER CONE (63T.)	16 K 190
1313 233 001	T14809	000 263 2020	ZF 47	78	SYNCHRONIZER CONE (63T.)	16 S 190
1313 233 001	T14809	000 263 2020	ZF 50	78	SYNCHRONIZER CONE (63T.)	16 S 150
1313 233 001	T14809	000 263 2020	ZF 55	82	SYNCHRONIZER CONE (63T.)	16 S 151
1313 302 035			ZF 50	1	CONSTANT GEAR (30T.)	16 S 150
1313 302 036			ZF 50	1	CONSTANT GEAR (34T.)	16 S 150
1313 303 002			ZF 50	37	COUNTERSHAFT THIRD SPEED GEAR (28T.)	16 S 150
1313 303 003			ZF 50	36	COUNTERSHAFT FOURTH SPEED GEAR (39T.)	16 S 150
1313 303 004			ZF 50	35	COUNTERSHAFT CONSTANT GEAR (37T.)	16 S 150
1313 303 010			ZF 50	38	COUNTERSHAFT (19-23T.)	16 S 150
1313 303 011			ZF 50	38	COUNTERSHAFT (17-20T.)	16 S 150
1313 303 035			ZF 50	39	COUNTERSHAFT (19-23T.)	16 S 150
1313 304 005			ZF 50	11	FOURTH SPEED GEAR (30T.)	16 S 150
1313 304 008			ZF 50	28	SYNCHRONIZER HUB	16 S 150
1313 304 008			ZF 51	28	SYNCHRONIZER HUB	16 S 220
1313 304 008			ZF 55	27	SYNCHRONIZER HUB	16 S 151
1313 304 008			ZF 56	27	SYNCHRONIZER HUB	16 S 181
1313 304 008			ZF 57	27	SYNCHRONIZER HUB	16 S 221
1313 304 008			ZF 58	20	SYNCHRONIZER HUB	16 S 251
1313 304 009			ZF 50	26	SYNCHRONIZER CONE	16 S 150
1313 304 009			ZF 51	26	SYNCHRONIZER CONE	16 S 220
1313 304 009			ZF 55	25	SYNCHRONIZER CONE	16 S 151
1313 304 009			ZF 56	25	SYNCHRONIZER CONE	16 S 181
1313 304 009			ZF 57	25	SYNCHRONIZER CONE	16 S 221
1313 304 009			ZF 58	18	SYNCHRONIZER CONE	16 S 251
1313 304 037			ZF 50	32	FIRST SPEED AND REVERSE GEAR CONE	16 S 150
1313 304 038			ZF 50	30	FIRST SPEED GEAR SLEEVE	16 S 150
1313 304 038			ZF 55	29	FIRST SPEED GEAR SLEEVE	16 S 151
1313 304 039			ZF 50	31	FIRST SPEED GEAR (44T.)	16 S 150
1313 304 041			ZF 50	34	REVERSE GEAR (38T.)	16 S 150
1313 304 042			ZF 50	34	REVERSE GEAR (39T.)	16 S 150
1313 304 070			ZF 50	31	FIRST SPEED GEAR	16 S 150
1313 304 072			ZF 50	17	MAINSHAFT	16 S 150
1313 304 077			ZF 50	18	SECOND SPEED GEAR (38T.)	16 S 150
1313 304 078			ZF 50	18	SECOND SPEED GEAR (37T.)	16 S 150
1313 304 080			ZF 50	16	THIRD SPEED GEAR (32T.)	16 S 150
1313 304 081			ZF 50	16	THIRD SPEED GEAR (34T.)	16 S 150
1313 305 001			ZF 50	41	REVERSE IDLER GEAR (24T.)	16 S 150
1313 305 002			ZF 50	41	REVERSE IDLER GEAR (21T.)	16 S 150
1313 332 020			ZF 50	70	RING GEAR CARRIER (86T.)	16 S 150
1313 332 020			ZF 55	70	RING GEAR CARRIER (86T.)	16 S 151

I riferimenti originali sono riportati solo come indicazione di particolari originali corrispondenti.
 All manufactures' names, numbers, symbols and descriptions are used for reference purposes only, and it is not implied that any part listed is the product of these manufacturers.

PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
1313 333 001			ZF 50	73	SYNCHRONIZER HUB	16 S 150
1313 333 001			ZF 55	73	SYNCHRONIZER HUB	16 S 151
1313 333 001			ZF 55	80	SYNCHRONIZER HUB	16 S 151
1313 333 001			ZF 56	74	SYNCHRONIZER HUB	16 S 181
1313 333 001			ZF 57	82	SYNCHRONIZER HUB	16 S 221
1313 333 001			ZF 58	75	SYNCHRONIZER HUB	16 S 251
1313 338 002			ZF 50	80	CARRIER COUPLING FLANGE	16 S 150
1313 338 002			ZF 55	84	CARRIER COUPLING FLANGE	16 S 151
1313 338 011			ZF 50	80	CARRIER COUPLING FLANGE	16 S 150
1313 338 011			ZF 55	84	CARRIER COUPLING FLANGE	16 S 151
1315 201 053			ZF 55	39	REVERSE IDLER GEAR SHAFT	16 S 151
1315 201 054			ZF 55	39	REVERSE IDLER GEAR SHAFT	16 S 151
1315 202 022			ZF 55	4	MAIN DRIVE GEAR	16 S 151
1315 202 037			ZF 55	4	MAIN DRIVE GEAR	16 S 151
1315 202 038			ZF 55	4	MAIN DRIVE GEAR	16 S 151
1315 202 039			ZF 55	4	MAIN DRIVE GEAR	16 S 151
1315 202 040			ZF 55	4	MAIN DRIVE GEAR	16 S 151
1315 202 041			ZF 55	4	MAIN DRIVE GEAR	16 S 151
1315 202 042			ZF 55	4	MAIN DRIVE GEAR	16 S 151
1315 202 043			ZF 55	4	MAIN DRIVE GEAR	16 S 151
1315 202 044			ZF 55	4	MAIN DRIVE GEAR	16 S 151
1315 202 045			ZF 55	4	MAIN DRIVE GEAR	16 S 151
1315 202 046			ZF 55	4	MAIN DRIVE GEAR	16 S 151
1315 202 047			ZF 55	4	MAIN DRIVE GEAR	16 S 151
1315 202 048			ZF 55	4	MAIN DRIVE GEAR	16 S 151
1315 202 050			ZF 55	4	MAIN DRIVE GEAR	16 S 151
1315 221 002			ZF 55	4	MAIN DRIVE GEAR	16 S 151
1315 232 001			ZF 55	68	GEAR SET (5 pcs.)	16 S 151
(1315 232 001/G)			ZF 55	67	GEAR	16 S 151
1315 232 010			ZF 55	68	GEAR SET (5 pcs.)	16 S 151
1315 232 010			ZF 56	68	GEAR SET (5 pcs.)	16 S 181
(1315 232 010/G)			ZF 55	67	GEAR	16 S 151
(1315 232 010/G)			ZF 56	67	GEAR	16 S 181
1315 232 016			ZF 55	60	CARRIER	16 S 151
1315 232 016			ZF 56	60	CARRIER	16 S 181
1315 232 017			ZF 55	60	CARRIER	16 S 151
1315 232 017			ZF 56	60	CARRIER	16 S 181
1315 232 023			ZF 50	60	CARRIER	16 S 150
1315 232 023			ZF 55	60	CARRIER	16 S 151
1315 233 006	T11732		ZF 55	71	SYNCHRONIZER FLANGE WITH CONE (63T.)	16 S 151
1315 233 006	T11732		ZF 57	72	SYNCHRONIZER FLANGE WITH CONE (63T.)	16 S 221
1315 233 023			ZF 55	83	SYNCHRONIZER CONE	16 S 151
1315 238 001			ZF 55	84	CARRIER COUPLING FLANGE	16 S 151
1315 302 007			ZF 55	1	CONSTANT GEAR (30T.)	16 S 151
1315 302 008			ZF 55	1	CONSTANT GEAR (34T.)	16 S 151
1315 302 045			ZF 55	41	MAIN DRIVE GEAR BEARING RETAINER	16 S 151
1315 302 047			ZF 55	41	MAIN DRIVE GEAR BEARING RETAINER	16 S 151
1315 302 047			ZF 57	40	MAIN DRIVE GEAR BEARING RETAINER	16 S 221
1315 302 057			ZF 55	41	MAIN DRIVE GEAR BEARING RETAINER	16 S 151
1315 302 057			ZF 57	40	MAIN DRIVE GEAR BEARING RETAINER	16 S 221
1315 302 072			ZF 55	40	MAIN DRIVE GEAR BEARING RETAINER	16 S 151
1315 302 072			ZF 56	39	MAIN DRIVE GEAR BEARING RETAINER	16 S 181
1315 302 072			ZF 57	39	MAIN DRIVE GEAR BEARING RETAINER	16 S 221
1315 302 075			ZF 55	40	MAIN DRIVE GEAR BEARING RETAINER	16 S 151
1315 302 075			ZF 56	39	MAIN DRIVE GEAR BEARING RETAINER	16 S 181
1315 302 075			ZF 57	39	MAIN DRIVE GEAR BEARING RETAINER	16 S 221
1315 302 084			ZF 57	39	MAIN DRIVE GEAR BEARING RETAINER	16 S 221
1315 302 106			ZF 55	40	MAIN DRIVE GEAR BEARING RETAINER	16 S 151
1315 302 106			ZF 57	39	MAIN DRIVE GEAR BEARING RETAINER	16 S 221
1315 302 113			ZF 55	41	MAIN DRIVE GEAR BEARING RETAINER	16 S 151
1315 302 113			ZF 57	40	MAIN DRIVE GEAR BEARING RETAINER	16 S 221
1315 302 124			ZF 55	40	MAIN DRIVE GEAR BEARING RETAINER	16 S 151
1315 302 124			ZF 56	39	MAIN DRIVE GEAR BEARING RETAINER	16 S 181
1315 302 124			ZF 57	39	MAIN DRIVE GEAR BEARING RETAINER	16 S 221
1315 302 134			ZF 55	40	MAIN DRIVE GEAR BEARING RETAINER	16 S 151
1315 302 134			ZF 57	39	MAIN DRIVE GEAR BEARING RETAINER	16 S 221
1315 302 134			ZF 58	32	MAIN DRIVE GEAR BEARING RETAINER	16 S 251
1315 302 136			ZF 55	40	MAIN DRIVE GEAR BEARING RETAINER	16 S 151
1315 302 136			ZF 56	39	MAIN DRIVE GEAR BEARING RETAINER	16 S 181
1315 302 136			ZF 57	39	MAIN DRIVE GEAR BEARING RETAINER	16 S 221
1315 302 141			ZF 55	40	MAIN DRIVE GEAR BEARING RETAINER	16 S 151
1315 302 141			ZF 56	39	MAIN DRIVE GEAR BEARING RETAINER	16 S 181
1315 302 141			ZF 57	39	MAIN DRIVE GEAR BEARING RETAINER	16 S 221
1315 302 157			ZF 55	1	CONSTANT GEAR (30T.)	16 S 151
1315 302 158			ZF 55	1	CONSTANT GEAR (35T.)	16 S 151
1315 302 161			ZF 55	40	MAIN DRIVE GEAR BEARING RETAINER	16 S 151

PROGRESSIVE ORIGINAL REFERENCES



PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
1315 302 161			ZF 56	39	MAIN DRIVE GEAR BEARING RETAINER	16 S 181
1315 302 161			ZF 57	39	MAIN DRIVE GEAR BEARING RETAINER	16 S 221
1315 302 161			ZF 58	32	MAIN DRIVE GEAR BEARING RETAINER	16 S 251
1315 302 173			ZF 55	1	CONSTANT GEAR (34T.)	16 S 151
1315 302 181			ZF 55	40	MAIN DRIVE GEAR BEARING RETAINER	16 S 151
1315 302 181			ZF 57	39	MAIN DRIVE GEAR BEARING RETAINER	16 S 221
1315 302 184			ZF 57	39	MAIN DRIVE GEAR BEARING RETAINER	16 S 221
1315 302 193			ZF 55	40	MAIN DRIVE GEAR BEARING RETAINER	16 S 151
1315 302 193			ZF 57	39	MAIN DRIVE GEAR BEARING RETAINER	16 S 221
1315 303 004			ZF 55	35	COUNTERSHAFT THIRD SPEED GEAR (26T.)	16 S 151
1315 303 008			ZF 55	33	COUNTERSHAFT CONSTANT GEAR (39T.)	16 S 151
1315 303 010			ZF 55	35	COUNTERSHAFT THIRD SPEED GEAR (28T.)	16 S 151
1315 303 020			ZF 55	36	COUNTERSHAFT	16 S 151
1315 303 022			ZF 55	36	COUNTERSHAFT	16 S 151
1315 303 030			ZF 55	37	COUNTERSHAFT	16 S 151
1315 303 041			ZF 55	36	COUNTERSHAFT	16 S 151
1315 303 042			ZF 55	36	COUNTERSHAFT	16 S 151
1315 303 046			ZF 55	34	COUNTERSHAFT FOURTH SPEED GEAR (39T.)	16 S 151
1315 303 048			ZF 55	36	COUNTERSHAFT	16 S 151
1315 303 049			ZF 55	36	COUNTERSHAFT	16 S 151
1315 303 050			ZF 55	34	COUNTERSHAFT FOURTH SPEED GEAR (35T.)	16 S 151
1315 303 051			ZF 55	33	COUNTERSHAFT CONSTANT GEAR (32T.)	16 S 151
1315 303 052			ZF 55	33	COUNTERSHAFT CONSTANT GEAR (37T.)	16 S 151
1315 304 004			ZF 55	30	FIRST SPEED GEAR (47T.)	16 S 151
1315 304 006			ZF 55	32	REVERSE GEAR (44T.)	16 S 151
1315 304 013			ZF 55	32	REVERSE GEAR (42T.)	16 S 151
1315 304 014			ZF 55	30	FIRST SPEED GEAR (44T.)	16 S 151
1315 304 017			ZF 55	9	FOURTH SPEED GEAR (30T.)	16 S 151
1315 304 018			ZF 55	31	FIRST SPEED AND REVERSE GEAR CONE	16 S 151
1315 304 025			ZF 55	17	SECOND SPEED GEAR (38T.)	16 S 151
1315 304 026			ZF 55	17	SECOND SPEED GEAR (37T.)	16 S 151
1315 304 027			ZF 55	14	THIRD SPEED GEAR (34T.)	16 S 151
1315 304 028			ZF 55	14	THIRD SPEED GEAR (32T.)	16 S 151
1315 304 029			ZF 55	15	MAINSHAFT	16 S 151
1315 304 089			ZF 55	9	FOURTH SPEED GEAR (32T.)	16 S 151
1315 304 130			ZF 55	15	MAINSHAFT	16 S 151
1315 304 131			ZF 55	15	MAINSHAFT	16 S 151
1315 304 132			ZF 50	33	REVERSE SPEED GEAR SLEEVE	16 S 150
1315 304 135			ZF 50	15	SYNCHRONIZER SLIDING COLLAR	16 S 150
1315 304 135			ZF 51	15	SYNCHRONIZER SLIDING COLLAR	16 S 220
1315 304 135			ZF 55	13	SYNCHRONIZER SLIDING COLLAR	16 S 151
1315 304 135			ZF 56	13	SYNCHRONIZER SLIDING COLLAR	16 S 181
1315 304 135			ZF 57	13	SYNCHRONIZER SLIDING COLLAR	16 S 221
1315 304 135			ZF 58	13	SYNCHRONIZER SLIDING COLLAR	16 S 251
1315 304 136			ZF 50	29	SYNCHRONIZER SLIDING COLLAR	16 S 150
1315 304 136			ZF 51	29	SYNCHRONIZER SLIDING COLLAR	16 S 220
1315 304 136			ZF 55	28	SYNCHRONIZER SLIDING COLLAR	16 S 151
1315 304 136			ZF 56	28	SYNCHRONIZER SLIDING COLLAR	16 S 181
1315 304 136			ZF 57	28	SYNCHRONIZER SLIDING COLLAR	16 S 221
1315 304 136			ZF 58	21	SYNCHRONIZER SLIDING COLLAR	16 S 251
1315 305 002			ZF 55	38	REVERSE IDLER GEAR (22T.)	16 S 151
1315 305 005			ZF 55	38	REVERSE IDLER GEAR (20T.)	16 S 151
1315 306 079			ZF 58	90	SLIDING BLOCK	16 S 251
1315 332 002			ZF 55	70	RING GEAR CARRIER (90T.)	16 S 151
1315 332 003			ZF 55	69	RING GEAR (90T.)	16 S 151
1315 332 041			ZF 55	69	RING GEAR (86T.)	16 S 151
1315 332 041			ZF 56	69	RING GEAR	16 S 181
1315 332 041			ZF 57	70	RING GEAR	16 S 221
1315 332 053			ZF 55	61	GEAR SHAFT	16 S 151
1315 332 053			ZF 56	61	GEAR SHAFT	16 S 181
1315 338 002			ZF 55	84	CARRIER COUPLING FLANGE	16 S 151
1316 201 029			ZF 56	38	REVERSE IDLER GEAR SHAFT	16 S 181
1316 201 029			ZF 57	38	REVERSE IDLER GEAR SHAFT	16 S 221
1316 201 030			ZF 57	38	REVERSE IDLER GEAR SHAFT	16 S 221
1316 201 075			ZF 58	31	REVERSE IDLER GEAR SHAFT	16 S 251
1316 202 025			ZF 56	4	MAIN DRIVE GEAR	16 S 181
1316 202 025			ZF 57	4	MAIN DRIVE GEAR	16 S 221
1316 202 025			ZF 58	4	MAIN DRIVE GEAR	16 S 251
1316 202 026			ZF 56	4	MAIN DRIVE GEAR	16 S 181
1316 202 026			ZF 57	4	MAIN DRIVE GEAR	16 S 221
1316 202 027			ZF 56	4	MAIN DRIVE GEAR	16 S 181
1316 202 027			ZF 57	4	MAIN DRIVE GEAR	16 S 221
1316 202 029			ZF 57	4	MAIN DRIVE GEAR	16 S 221
1316 202 030			ZF 57	4	MAIN DRIVE GEAR	16 S 221
1316 202 031			ZF 56	4	MAIN DRIVE GEAR	16 S 181
1316 202 031			ZF 57	4	MAIN DRIVE GEAR	16 S 221

I riferimenti originali sono riportati solo come indicazione di particolari originali corrispondenti.
 All manufactures' names, numbers, symbols and descriptions are used for reference purposes only, and it is not implied that any part listed is the product of these manufacturers.

PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
1316 202 032			ZF 57	4	MAIN DRIVE GEAR	16 S 221
1316 202 033			ZF 57	4	MAIN DRIVE GEAR	16 S 221
1316 202 033			ZF 58	4	MAIN DRIVE GEAR	16 S 251
1316 202 036			ZF 57	4	MAIN DRIVE GEAR	16 S 221
1316 202 037			ZF 57	4	MAIN DRIVE GEAR	16 S 221
1316 202 038			ZF 56	4	MAIN DRIVE GEAR	16 S 181
1316 202 038			ZF 57	4	MAIN DRIVE GEAR	16 S 221
1316 202 039			ZF 56	4	MAIN DRIVE GEAR	16 S 181
1316 202 039			ZF 57	4	MAIN DRIVE GEAR	16 S 221
1316 221 017			ZF 56	4	MAIN DRIVE GEAR	16 S 181
1316 221 017			ZF 57	4	MAIN DRIVE GEAR	16 S 221
1316 221 018			ZF 57	4	MAIN DRIVE GEAR	16 S 221
1316 232 005			ZF 47	60	CARRIER	16 S 190
1316 232 006			ZF 51	60	CARRIER	16 S 220
1316 232 006			ZF 57	60	CARRIER	16 S 221
1316 232 011			ZF 56	68	GEAR SET (5 pcs.)	16 S 181
(1316 232 011/G)			ZF 56	67	GEAR	16 S 181
1316 232 017			ZF 58	68	GEAR SET (5 pcs.)	16 S 251
(1316 232 017/G)			ZF 58	67	GEAR	16 S 251
1316 232 019			ZF 56	60	CARRIER	16 S 181
1316 232 019			ZF 57	60	CARRIER	16 S 221
1316 232 028			ZF 55	84	CARRIER COUPLING FLANGE	16 S 151
1316 233 010			ZF 57	79	SYNCHRONIZER CONE	16 S 221
1316 233 014			ZF 55	83	SYNCHRONIZER CONE	16 S 151
1316 233 014			ZF 56	80	SYNCHRONIZER CONE	16 S 181
1316 233 014			ZF 57	84	SYNCHRONIZER CONE	16 S 221
1316 233 015			ZF 55	82	SYNCHRONIZER CONE	16 S 151
1316 233 015			ZF 57	84	SYNCHRONIZER CONE	16 S 221
1316 233 015			ZF 58	80	SYNCHRONIZER CONE	16 S 251
1316 233 015			ZF 56	79	SYNCHRONIZER CONE	16 S 181
1316 302 057			ZF 56	1	CONSTANT GEAR (35T.)	16 S 181
1316 302 065			ZF 57	1	CONSTANT GEAR (34T.)	16 S 221
1316 302 066			ZF 56	1	CONSTANT GEAR	16 S 181
1316 302 066			ZF 57	1	CONSTANT GEAR	16 S 221
1316 302 067			ZF 57	1	CONSTANT GEAR (35T.)	16 S 221
1316 302 067			ZF 58	1	CONSTANT GEAR (35T.)	16 S 251
1316 303 001			ZF 57	33	COUNTERSHAFT CONSTANT GEAR (39T.)	16 S 221
1316 303 002			ZF 57	33	COUNTERSHAFT CONSTANT GEAR (37T.)	16 S 221
1316 303 004			ZF 57	34	COUNTERSHAFT FOURTH SPEED GEAR (39T.)	16 S 221
1316 303 005			ZF 57	35	COUNTERSHAFT THIRD SPEED GEAR (26T.)	16 S 221
1316 303 006			ZF 57	35	COUNTERSHAFT THIRD SPEED GEAR (28T.)	16 S 221
1316 303 007			ZF 57	36	COUNTERSHAFT (17-20T.)	16 S 221
1316 303 008			ZF 57	36	COUNTERSHAFT (19-23T.)	16 S 221
1316 303 030			ZF 57	33	COUNTERSHAFT CONSTANT GEAR (39T.)	16 S 221
1316 303 031			ZF 57	33	COUNTERSHAFT CONSTANT GEAR (37T.)	16 S 221
1316 303 033			ZF 56	36	COUNTERSHAFT (17-20T.)	16 S 181
1316 303 033			ZF 57	36	COUNTERSHAFT (17-20T.)	16 S 221
1316 303 034			ZF 57	36	COUNTERSHAFT	16 S 221
1316 303 038			ZF 58	29	COUNTERSHAFT (17-20T.)	16 S 251
1316 303 040			ZF 58	28	COUNTERSHAFT THIRD SPEED GEAR (26T.)	16 S 251
1316 303 055			ZF 56	33	COUNTERSHAFT CONSTANT GEAR (39T.)	16 S 181
1316 303 056			ZF 56	33	COUNTERSHAFT CONSTANT GEAR (32T.)	16 S 181
1316 303 058			ZF 56	35	COUNTERSHAFT THIRD SPEED GEAR (26T.)	16 S 181
1316 303 063			ZF 56	34	COUNTERSHAFT FOURTH SPEED GEAR (35T.)	16 S 181
1316 303 064			ZF 57	33	COUNTERSHAFT CONSTANT GEAR	16 S 221
1316 303 064			ZF 58	26	COUNTERSHAFT CONSTANT GEAR	16 S 251
1316 303 065			ZF 57	34	COUNTERSHAFT FOURTH SPEED GEAR (35T.)	16 S 221
1316 303 065			ZF 58	27	COUNTERSHAFT FOURTH SPEED GEAR (35T.)	16 S 251
1316 304 001			ZF 57	15	MAINSHAFT	16 S 221
1316 304 002			ZF 56	17	SECOND SPEED GEAR (38T.)	16 S 181
1316 304 002			ZF 57	17	SECOND SPEED GEAR (38T.)	16 S 221
1316 304 002			ZF 58	17	SECOND SPEED GEAR (38T.)	16 S 251
1316 304 003			ZF 57	17	SECOND SPEED GEAR (37T.)	16 S 221
1316 304 007			ZF 57	9	FOURTH SPEED GEAR (30T.)	16 S 221
1316 304 008			ZF 57	14	THIRD SPEED GEAR (34T.)	16 S 221
1316 304 009			ZF 57	14	THIRD SPEED GEAR (32T.)	16 S 221
1316 304 010			ZF 56	30	FIRST SPEED GEAR (47T.)	16 S 181
1316 304 010			ZF 57	30	FIRST SPEED GEAR (47T.)	16 S 221
1316 304 010			ZF 58	23	FIRST SPEED GEAR (47T.)	16 S 251
1316 304 012			ZF 56	32	REVERSE GEAR (44T.)	16 S 181
1316 304 012			ZF 57	32	REVERSE GEAR (44T.)	16 S 221
1316 304 012			ZF 58	25	REVERSE GEAR (44T.)	16 S 251
1316 304 013			ZF 57	30	FIRST SPEED GEAR (44T.)	16 S 221
1316 304 015			ZF 57	32	REVERSE GEAR	16 S 221
1316 304 066			ZF 58	14	THIRD SPEED GEAR (34T.)	16 S 251
1316 304 078			ZF 50	29	SYNCHRONIZER SLIDING COLLAR	16 S 150

PROGRESSIVE ORIGINAL REFERENCES



PART No.	TAS No.	Mercedes No.	TAB.	KEY	DESCRIPTION	MODEL
1316 304 078			ZF 51	29	SYNCHRONIZER SLIDING COLLAR	16 S 220
1316 304 078			ZF 55	28	SYNCHRONIZER SLIDING COLLAR	16 S 151
1316 304 078			ZF 56	28	SYNCHRONIZER SLIDING COLLAR	16 S 181
1316 304 078			ZF 57	28	SYNCHRONIZER SLIDING COLLAR	16 S 221
1316 304 078			ZF 58	21	SYNCHRONIZER SLIDING COLLAR	16 S 251
1316 304 092			ZF 58	16	MAINSHAFT TUBE	16 S 251
1316 304 093			ZF 58	16	MAINSHAFT TUBE	16 S 251
1316 304 094			ZF 56	14	THIRD SPEED GEAR (34T.)	16 S 181
1316 304 103			ZF 56	9	FOURTH SPEED GEAR (32T.)	16 S 181
1316 304 103			ZF 57	9	FOURTH SPEED GEAR (32T.)	16 S 221
1316 304 103			ZF 58	9	FOURTH SPEED GEAR (32T.)	16 S 251
1316 304 130			ZF 57	15	MAINSHAFT	16 S 221
1316 304 131			ZF 58	15	MAINSHAFT	16 S 251
1316 304 132			ZF 56	15	MAINSHAFT	16 S 181
1316 304 132			ZF 57	15	MAINSHAFT	16 S 221
1316 304 133			ZF 51	33	REVERSE SPEED GEAR SLEEVE	16 S 220
1316 304 145			ZF 50	12	SYNCHRONIZER CONE	16 S 150
1316 304 145			ZF 51	12	SYNCHRONIZER CONE	16 S 220
1316 304 145			ZF 55	10	SYNCHRONIZER CONE	16 S 151
1316 304 145			ZF 56	10	SYNCHRONIZER CONE	16 S 181
1316 304 145			ZF 57	10	SYNCHRONIZER CONE	16 S 221
1316 304 145			ZF 58	10	SYNCHRONIZER CONE	16 S 251
1316 304 146			ZF 50	26	SYNCHRONIZER CONE	16 S 150
1316 304 146			ZF 51	26	SYNCHRONIZER CONE	16 S 220
1316 304 146			ZF 55	25	SYNCHRONIZER CONE	16 S 151
1316 304 146			ZF 56	25	SYNCHRONIZER CONE	16 S 181
1316 304 146			ZF 57	25	SYNCHRONIZER CONE	16 S 221
1316 304 146			ZF 58	18	SYNCHRONIZER CONE	16 S 251
1316 304 147			ZF 50	14	SYNCHRONIZER HUB	16 S 150
1316 304 147			ZF 51	14	SYNCHRONIZER HUB	16 S 220
1316 304 147			ZF 55	12	SYNCHRONIZER HUB	16 S 151
1316 304 147			ZF 56	12	SYNCHRONIZER HUB	16 S 181
1316 304 147			ZF 57	12	SYNCHRONIZER HUB	16 S 221
1316 304 147			ZF 58	12	SYNCHRONIZER HUB	16 S 251
1316 304 148			ZF 50	28	SYNCHRONIZER HUB	16 S 150
1316 304 148			ZF 51	28	SYNCHRONIZER HUB	16 S 220
1316 304 148			ZF 55	27	SYNCHRONIZER HUB	16 S 151
1316 304 148			ZF 56	27	SYNCHRONIZER HUB	16 S 181
1316 304 148			ZF 57	27	SYNCHRONIZER HUB	16 S 221
1316 304 148			ZF 58	20	SYNCHRONIZER HUB	16 S 251
1316 304 149			ZF 50	13	SYNCHRONIZER BLOCKING RING	16 S 150
1316 304 149			ZF 51	13	SYNCHRONIZER BLOCKING RING	16 S 220
1316 304 149			ZF 55	11	SYNCHRONIZER BLOCKING RING	16 S 151
1316 304 149			ZF 56	11	SYNCHRONIZER BLOCKING RING	16 S 181
1316 304 149			ZF 57	11	SYNCHRONIZER BLOCKING RING	16 S 221
1316 304 149			ZF 58	11	SYNCHRONIZER BLOCKING RING	16 S 251
1316 304 150			ZF 50	27	SYNCHRONIZER BLOCKING RING	16 S 150
1316 304 150			ZF 51	27	SYNCHRONIZER BLOCKING RING	16 S 220
1316 304 150			ZF 55	26	SYNCHRONIZER BLOCKING RING	16 S 151
1316 304 150			ZF 56	26	SYNCHRONIZER BLOCKING RING	16 S 181
1316 304 150			ZF 57	26	SYNCHRONIZER BLOCKING RING	16 S 221
1316 304 150			ZF 58	19	SYNCHRONIZER BLOCKING RING	16 S 251
1316 305 001			ZF 56	37	REVERSE IDLER GEAR (22T.)	16 S 181
1316 305 001			ZF 57	37	REVERSE IDLER GEAR (22T.)	16 S 221
1316 305 001			ZF 58	30	REVERSE IDLER GEAR (22T.)	16 S 251
1316 305 002			ZF 57	37	REVERSE IDLER GEAR (20T.)	16 S 221
1316 306 015			ZF 55	90	SLIDING BLOCK	16 S 151
1316 306 015			ZF 56	90	SLIDING BLOCK	16 S 181
1316 306 015			ZF 57	92	SLIDING BLOCK	16 S 221
1316 306 015			ZF 58	90	SLIDING BLOCK	16 S 251
1316 332 042			ZF 58	69	RING GEAR	16 S 251
1316 332 044			ZF 58	70	RING GEAR THRUST RING	16 S 251
1316 332 073			ZF 58	71	RING GEAR CARRIER	16 S 251
1316 332 096			ZF 56	61	GEAR SHAFT	16 S 181
1316 332 096			ZF 57	61	GEAR SHAFT	16 S 221
1316 332 097			ZF 58	61	GEAR SHAFT	16 S 251
1316 332 103			ZF 55	70	RING GEAR CARRIER (86T.)	16 S 151
1316 332 103			ZF 56	70	RING GEAR CARRIER	16 S 181
1316 332 103			ZF 57	71	RING GEAR CARRIER	16 S 221
1316 333 026			ZF 58	72	SYNCHRONIZER CLUTCH DISC	16 S 251
1316 338 002			ZF 57	85	CARRIER COUPLING FLANGE	16 S 221
1316 338 003			ZF 57	85	CARRIER COUPLING FLANGE	16 S 221
4130 306 301			ZF 55	40	MAIN DRIVE GEAR BEARING RETAINER	16 S 151
4130 306 306			ZF 57	39	MAIN DRIVE GEAR BEARING RETAINER	16 S 221
4130 306 306			ZF 58	32	MAIN DRIVE GEAR BEARING RETAINER	16 S 251

I riferimenti originali sono riportati solo come indicazione di particolari originali corrispondenti.
 All manufactures' names, numbers, symbols and descriptions are used for reference purposes only, and it is not implied that any part listed is the product of these manufacturers.